Original		Replacement	
	Power		Power
TV/DTV	Tv/DTV	PROGRAM TV/RADIO	TV/Radio /
1	Input1	SHIFT + TV 1	Shift + 1
INI 2	Input2	SHIFT + DVD 2	Shift + 2
UT 3	Input3	SHIFT + CD-STB 3	Shift + 3
4	Input4	SHIFT + VIDEO 4	Shift + 4
	[I>I<]/[≡+]	TOP MENU D.MENU	D.Menu / Top
	[<>]/[≡♦]	FORMAT PICTURE	Picture / Format
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9

Original		Replacement	
	[i+]/Info	ANGLE INFO	Info / Angle
0	0	HDMI-SAT 0	0
P	P+	+ CH PAGE	CH+ / Page+
I-II	I-II	LANG I/II AUDIO	Audio / Lang I/II
	Vol+	+ VOL	Vol+
P	P-	CH PAGE −	CH- / Page-
	Mute	DIMMER MUTE	Mute / Dimmer
	Vol-	VOL −	Vol-
RETURN	Return	RETURN BACK	Back / Return
	Up		Up
HOME MENU	Home Menu	HOME MENU	Menu / Home
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down		Down
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--

Original	Replacement	Original	Replacement
Red	Red / Netflix / Search		
Green	Green / APP / Repeat		
Yellow	Yellow / YouTube / Repeat		
Blue	Blue / Prime Video / Random		
[....]	Subtitle / EQ		
[≡?]	Display / Media		
[≡i]	Smart / List		
[≡]	Text / Goto		