Mandis shop

Thomson CS186

Original	Replacement
On	Power
Source	AV
Up	Up
Down	Down
Right	Right
Left	Left
Vol+	Vol +
Vol-	Vol -
Play	Play
Pause	Pause
Stop	Stop
Record	Rec
Open/Close	Eject
>>I	>>I
I<<	I<<
Mute	Mute
Prog	Shift + Sleep

Original	Replacement
Intro/CT	Ok
Clock	Smart
ADD	3D
PTY	Options
Del	Exit
Timer	Shift + AV
Repeat/RDS	Text
Sleep	Sleep
Band	Red
FM ST	Green
CD Info	Yellow
Demo/Dimmer	Media
EQ	Dual
B.Boost	Back

https://all-remote-controls.co.uk/en/Thomson/1056018-77967-replacement-remote-control-for-Thomson-CS186-56124100.html