Original	Replacement	Original	Replacement
Power	Power	Right	Right
[X]	Exit / Cancel / Clear	Vol +	Vol +
[◆]	Zoom / Size	Down	Down
[+]	Stop / Hold	P+	CH+ / Page+
[?]/[:≡]	Play / Slow	Vol -	Vol -
I.S.	Smart / List	Mute	Mute / Dimmer
[i+]	Info / Angle	P-	CH- / Page-
Sleep	Sleep / Timer	Red	Red / Netflix / Search
[<>]	Setup / OPT /	Green	Green / APP / Repeat
Smart ♪	Sound / Title	Yellow	Yellow / YouTube / Repeat
Radio	TV/Radio /	Blue	Blue / Prime Video / Random
Smart [ ]	Picture / Format	1	1
Menu	Menu / Home	2	2
Up	Up	3	3
[≡]	Text / Goto	4	4
OK	OK	5	5
Left	Left	6	6

Original		Replacement		Original	Replacement
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
	Sour ce	RDS AV INPUT	AV / I nput / RDS		
0	0	HDMI - SAT 0	0		
I-II	I - I I	LANG I/II AUDIO	Audi o / Lang I / I I		

Original	Replacement
Power	Power
Prog	TV/ Radio /
>>	>> / Tune+
Menu	Menu / Home
Up	Up
OK	OK
Left	Left
Right	Right
Down	Down
P+	CH+ / Page+
P-	CH- / Page-
Rec	Rec / Rec Mode
<<	<< / Tune-
Stop	Stop / Hold
Play	Play / Slow
1	1
2	2

Original	Replacement
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Source	AV / Input / RDS
0	0