Original		Replacement	
	Power		Power
	Source	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2 abc	2	DVD 2	2
3 def	3	CD - STB 3	3
4 ghi	4	VIDEO 4	4
5 jkl	5	TAPE 5	5
6 mno	6	TUNER 6	6
7 pqrs	7	AUX - HDD 7	7
8 tuv	8	USB 8	8
9 wxyz	9	BLUETOOTH 9	9
LANG.	Lang	LANG I/II AUDIO	Audio / Lang I/II
0	0	HDMI - SAT 0	0
TXT	TXT	GOTO TEXT	Text / Goto
	Home	LIST SMART	Smart / List
	Home	TOP MENU D.MENU	D. Menu / Top
+ V	Vol +	+ VOL	Vol +

Original		Replacement	
P ^	P+	+ CH PAGE	CH+ / Page+
– V	Vol -	VOL –	Vol -
P v	P-	CH PAGE –	CH- / Page-
	Mute	DIMMER MUTE	Mute / Dimmer
G	[G]	HOME MENU	Menu / Home
	Up		Up
i	i	ANGLE INFO	Info / Angle
	Left		Left
OK	OK	OK	OK
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	<<	TUNE-	<< / Tune-
	Pause	STEP - FREEZE	Pause / Step / Freeze
	>>	TUNE+	>> / Tune+
	Rec	REC MODE	Rec / Rec Mode

Original	Replacement	Original	Replacement
Play	SLOW Play / Slow		
Stop	HOLD Stop / Hold		
Red	NETFLIX SEARCH Red / Netflix / Search		
Green	APP REPEAT Green / APP / Repeat		
Yellow	YouTube REPEAT A-B Yellow / YouTube / Repeat		
Blue	Prime Video RANDOM Blue / Prime Video / Random		