Mandis shop

# Sony RM-SR110

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| FUNCTION | Play Function | C | Yellow |
| TAPE B | Play Tape B | B | Green |
| TUNER/BAND | Play Tuner / Band | SEARCH TV/R | TV/R |
| TAPE A | Play Tape A | A | Red |
| FLASH | Flash | DISPLAY INFO | Info |
| LOOP | Loop | RETURN BACK | Back |
| FILE SELECT | File Select | APP MEDIA | Media |
| MODE SELECT | Mode Select | HOME SMART | Smart |
| VOL | Vol + | + VOL | Vol + |
| | Vol - | VOL − | Vol - |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| ENTER | Enter | OK | Ok |
| | >> | | >> |

| Original | | Replacement | |
|---|---|---|---|
| | << | | << |
| | >>I / + | | >>I |
| | I<< / - | | I<< |
| | Stop | | Stop |
| | Pause | | Pause |
| CD | Play CD | PLAY MODE | Play |
| DISC SKIP | Disc Skip | CLEAR EXIT | Exit |
| SLEEP | Sleep | PROG SLEEP | Sleep |

https://all-remote-controls.co.uk/en/Sony/1057363-91101-replacement-remote-control-for-Sony-RMSR110-141886211.html