Original		Replacement	
Power	Power	Power	Power
TV/SAT	Tv/SAT	HOME SMART	Smart
MUTE	Mute	MUTE	Mute
TV/R	TV/R	SEARCH TV/R	TV/R
GOTO	Goto	SETTINGS OPT	Options
AUDIO	Audio	SOUND DUAL	Dual
ASPECT	Aspect	ECO 3D	3D
INFO	Info	DISPLAY INFO	Info
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9

Original		Replacement	
0	0	0	0
P+	P+	+ CH	Ch +
P-	P-	CH –	Ch -
RECALL	Recall	RETURN BACK	Back
DEV	DEV	APP MEDIA	Media
CH	Up/CH+		Up
CH	Down/CH-		Down
VOL	Right		Right
VOL	Left		Left
OK	OK	OK	Ok
VOL	Vol+	+ VOL	Vol +
VOL	Vol-	VOL –	Vol -
MENU	Menu	TOP MENU MENU	Menu
EPG	EPG	-/-- GUIDE	Guide
FAV	FAV	FAV PRE-CH	Pre Ch
EXIT	Exit	CLEAR EXIT	Exit
TTX	TTX	REPEAT TEXT	Text

Original		Replacement	
TTX	Red	A	Red
SUB.T	Green	B	Green
ZOOM	Yellow	C	Yellow
OPTION	Blue/Option	D	Blue
SUB.T	Subt.	AD SUBT	Subt
ZOOM	Zoom	ZOOM	Eject
	<<		<<
	>>		>>
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
REC	Rec	REC MODE	Rec
MP	MP	TIMER AV	AV
V.FORMAT	V-Format	PICTURE FORMAT	Format
	A1	DISC NAV LIST	List
	B2	PROG SLEEP	Sleep

Original	Replacement