Original		Replacement	
	Power		Power
TV	TV	1	1
HDMI	HDMI	2	2
BLUETOOTH	Bluetooth	3	3
ANALOG	Analog	4	4
USB	USB	5	5
AUTO SOUND	Auto Sound	6	6
CINEMA	Cinema	7	7
MUSIC	Music	8	8
GAME	Game	9	9
NEWS	News	GUIDE	Guide
SPORTS	Sports	0	0
STANDARD	Standard	PRE-CH	Pre Ch
VOICE	Voice	3D	3D
VERTICAL S.	Vertical S.	SUBT	Subt
NIGHT	Night	EXIT	Exit
DISPLAY	Display	INFO	Info

Original		Replacement	
DIMMER	Dimmer	MEDIA	Media
BACK	Back	BACK	Back
OPTIONS	Options	OPT	Options
HOME	Home	SMART	Smart
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK	OK	Ok
AUDIO	Audio	DUAL	Dual
	Vol+	VOL +	Vol +
	Vol-	VOL −	Vol -
	Mute	MUTE	Mute
SW +	SW Vol+	CH +	Ch +
−	SW Vol-	CH −	Ch -
	I<<		I<<
	Play		Play

Original		Replacement		Original	Replacement
	Pause		Pause		
	>>I		>>I		