Original	Replacement	Original	Replacement
Power	Power	Exit	Exit
Mute	Mute	Up	Up
1	1	Down	Down
2	2	Right	Right
3	3	Left	Left
4	4	OK	Ok
5	5	P+	Ch +
6	6	P-	Ch -
7	7	Vol +	Vol +
8	8	Vol -	Vol -
9	9	Red	Red
0	0	Green	Green
Recall	Pre Ch	Yellow	Yellow
Input	AV	Blue	Blue
Menu	Menu	♪	Shift + Dual
[<>]	Format	PC Input	Smart
→[/] ←	Subt	[i+]	Info

Original		Replacement		Original	Replacement
	O) I / I I	SOUND DUAL	Dual		
	[▼]	SEARCH TV/R	TV/ R		
	[≡] / [/ ≡] / [ ]	REPEAT TEXT	Text		
	[≡i]	DISC NAV LIST	Li st		
	[≡O]	RETURN BACK	Back		
	[≡?]	-/-- GUIDE	Gui de		
	[≡+]	APP MEDIA	Medi a		
	[≡♦]	ECO 3D	3D		
	[O] / [≡x]	ZOOM ⏏	Ej ect		

Original		Replacement	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
DVD MENU	Menu DVD	TOP MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left

Original		Replacement	
OK	OK	OK	Ok
P+	P+	CH +	Ch +
P-	P-	CH -	Ch -
	Vol +	VOL +	Vol +
	Vol -	VOL -	Vol -
	Pause/Step		Pause
	Play	PLAY MODE	Play
	<<		<<
	>>		>>
	Open/Close	ZOOM	Eject
	Stop		Stop
	I<<		I<<
	>>I		>>I

Original	Replacement	Original	Replacement
Power	Power	Play	Play
1	1	<<	<<
2	2	>>	>>
3	3	Eject	Eject
4	4	Stop	Stop
5	5	I<<	I<<
6	6	>>I	>>I
7	7		
8	8		
9	9		
0	0		
Input	AV		
Up	Up		
Down	Down		
P+	Ch +		
P-	Ch -		
Pause/Step	Pause		