Original	Replacement
Power	Power
Red/Rec/Instant	Red
Green/<<	Green
Yellow/Stop	Yellow
Blue/play	Blue
White/>>/□	>>
>♦	D. Menu
[I]	Guide
[o]/Timer	Sleep
[?]	Eject
[♦]	Format
[≡]/Text	Text
Menu	Menu
OK	Ok
Up	Up
Down	Down
Right	Right

Original	Replacement
Left	Left
Vol+	Vol +
Vol-	Vol -
Mute	Mute
P+	Ch +
P-	Ch -
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
P<P	Pre Ch

Original		Replacement	
	[i+]	DISPLAY INFO	Info
I-II	I-II	SOUND DUAL	Dual
	[>I<]	AD SUBT	Subt
	[1I2]	ECO 3D	3D
	[ ]→	TIMER AV	AV
	♪ Smart	HOME SMART	Smart
	[ ] Smart	APP MEDIA	Media
	[I<>I]	RETURN BACK	Back
ACTIVE CONTROL	[-o-]/Active Control	SETTINGS OPT	Options

Original	Replacement

Original	Replacement
Power	Power
Red/Rec/Instant	Red
Green/<<	Green
Yellow/Stop	Yellow
Blue/Play	Blue
White/>>/□	>>
[o]/Timer	Sleep
[?]	Eject
[♦]	Format
[≡]/Text	Text
Menu	Menu
OK	Ok
Up	Up
Down	Down
Right	Right
Left	Left
Vol+	Vol +

Original	Replacement
Vol-	Vol -
Mute	Mute
P+	Ch +
P-	Ch -
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
P<P	Pre Ch
[i+]	Info
I-II	Dual

Original		Replacement	
	[>I<]	AD SUBT	Subt
	[1I2]	ECO 3D	3D
	[ ]→	TIMER AV	AV
	♪ Smart	HOME SMART	Smart
	[ ] Smart	APP MEDIA	Media
	[I<>I]	RETURN BACK	Back
ACTIVE CONTROL	[-o-]/Active Control	SETTINGS OPT	Options

Original	Replacement

Original		Replacement	
	Power		Power
	Red/Rec/Instant		Red
	Green/<<		Green
	Yellow/Stop		Yellow
	Blue/Play		Blue
	White/>>/□		>>
	[o]/Timer		Sleep
	[?]		Eject
	[♦]		Format
	[≡]/Text		Text
	Menu		Menu
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Vol+		Vol +

Original		Replacement	
	Vol-		Vol -
	Mute		Mute
	P+		Ch +
	P-		Ch -
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	P<P		Pre Ch
	[i+]		Info
	I-II		Dual

Original		Replacement	
	[>I<]	AD SUBT	Subt
	[1I2]	ECO 3D	3D
	[ ]→	TIMER AV	AV
	♪ Smart	HOME SMART	Smart
	[ ] Smart	APP MEDIA	Media
	[I<>I]	RETURN BACK	Back
ACTIVE CONTROL	[-o-]/Active Control	SETTINGS OPT	Options

Original	Replacement