Mandis shop

Denon RC-174

Original		Replacement	
A/B	A/B Tape Deck	YouTube / REPEAT A-B	Yellow / YouTube / Repeat
A/B	A/B Tape Deck	LIST / SMART	Smart / List
REC	Rec Tape Deck	REC MODE	Rec / Rec Mode
PAUSE	Pause Tape	ANGLE / INFO	Info / Angle
STOP	Stop Tape Deck	OK	OK
POWER	Power		Power
REW	<< Tape Deck		Down
FF	>> Tape Deck		Up
PLAY	< Play Tape Deck		Left
PLAY	Play > Tape Deck		Right
	I<< CD	PRESET-	I<< / Preset-
	>>I CD	PRESET+	>>I / Preset+
RANDOM	Random CD	Prime Video / RANDOM	Blue / Prime Video / Random
REPEAT	Repeat CD	APP / REPEAT	Green / APP / Repeat
DISC SKIP	Disc Skip CD	SURROUND	Eject / Surround
PAUSE	Pause CD	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop CD	HOLD	Stop / Hold

Original		Replacement	
PLAY	Play CD	SLOW	Play / Slow
PANEL	Panel	TV 1	1
TAPE MONITOR	Tape Monitor	DVD 2	2
TAPE-2	Tape-2	USB 8	8
TAPE-1	Tape-1	TAPE 5	5
VIDEO	Video	VIDEO 4	4
TUNER	Tuner	TUNER 6	6
CD	CD	CD-STB 3	3
PHONO	Phono	AUX-HDD 7	7
PRESET	Preset Up	CH PAGE +	CH+ / Page+
PRESET	Preset Up	SHIFT + PRESET+	Shift + >>I / Preset+
VOLUME	Vol+	VOL +	Vol+
PRESET	Preset Down	CH PAGE −	CH- / Page-
PRESET	Preset Down	SHIFT + PRESET-	Shift + I<< / Preset-
VOLUME	Vol-	VOL −	Vol-

https://all-remote-controls.co.uk/en/Denon/1058222-18202-replacement-remote-control-for-Denon-RC-174-3990242108.html