Mandis shop

193334-B10

| Original | | Replacement | |
|---|---|---|---|
| On Off | On / Off | | Power |
| Sleep | Sleep | PROG SLEEP | Sleep |
| Volume | Volume + | VOL + | Vol + |
| Volume | Volume - | VOL − | Vol - |
| CD | CD Play/Pause | PLAY MODE ▶ | Play |
| CD | CD Play/Pause | ⏸ | Pause |
| CD ■ | CD Stop | ■ | Stop |
| FM | FM | CH + | Ch + |
| AM | AM | CH − | Ch - |
| AUX | AUX | APP MEDIA | Media |
| Track Tune | Track - / Tune - | ◀ | Left |
| Track Tune | Track - / Tune - | ⏮ | I<< |
| Track Tune | Track - / Tune - | ≪ | << |
| Track Tune | Track + / Tune + | ▶ | Right |
| Track Tune | Track + / Tune + | ≫ | >> |
| Track Tune | Track + / Tune + | ⏭ | >>I |
| Mute | Mute | MUTE | Mute |

| Original | | Replacement | |
|---|---|---|---|
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |

https://all-remote-controls.co.uk/en/BOSE/1058485-91402-replacement-remote-control-for-BOSE-WAVE-RADIO-CD-White-193334-B10.html