Mandis shop

# Sony RM-S171

| Original | | Replacement | |
|---|---|---|---|
| I/⏻ | Power | | Power |
| DISPLAY | Display | DISPLAY INFO | Info |
| DSG | DSG | ZOOM ⏏ | Eject |
| CD ▶ | Play CD | PLAY MODE ▶ | Play |
| ⏸ | Pause CD | ⏸ | Pause |
| ■ | Stop CD | ■ | Stop |
| TUNER/BAND | Play | SHIFT + PLAY MODE ▶ | Shift + Play |
| ⏮ | I<</- Tuner | ⏮ | I<< |
| ⏭ | >>I/+ Tuner | ⏭ | >>I |
| TAPE ◀▶ | Play/<> Tape | SETTINGS OPT | Options |
| ◀◀ | << Tape | ◀◀ | << |
| ▶▶ | >> Tape | ▶▶ | >> |
| DIR MODE | Play Dir Mode | HOME SMART | Smart |
| FM MODE | FM Mode | SOUND DUAL | Dual |
| REC | Rec | REC MODE | Rec |
| CD REPEAT | CD Repeat | REPEAT TEXT | Text |
| FUNCTION | Function | TOP MENU MENU | Menu |

| Original | | Replacement | |
|---|---|---|---|
| TUNING MODE/PLAY MODE | Tuning Mode/Play Mode | PICTURE FORMAT | Format |
| MEMORY | Up/Memory | ▲ | Up |
| SLEEP | Down/Sleep | ▼ | Down |
| TIMER SELECT | Right/Timer | ▶ | Right |
| TIMER SET | Left/Timer Set | ◀ | Left |
| ENTER ON/OFF | Enter/On/Off | OK | Ok |
| VOL + | Vol+ | + VOL | Vol + |
| VOL − | Vol- | VOL − | Vol - |

https://all-remote-controls.co.uk/en/Sony/1058653-5964-replacement-remote-control-for-Sony-RM-S171-147723911.html