Mandis shop

Panasonic RAK-RX416WH

Original		Replacement	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
DISPLAY	Display	DISPLAY INFO	Info
RANDOM	Random CD	HOME SMART	Smart
REPEAT	Repeat CD	REPEAT TEXT	Text
I<< CD		I<<	
>>I CD		>>I	
/CLEAR	Stop/Clear CD		Stop
	Play/Pause CD	PLAY MODE	Play
REV MODE	Rev Mode Tape	ECO 3D	3D
REW TPS	REW Tape	<<	
TPS FF	FF Tape	>>	
	Stop Tape	SHIFT +	Shift + Stop
<> Tape			Pause
C-RESET	C-Reset Tape	CLEAR EXIT	Exit
DECK 1/2	Deck 1/2	APP MEDIA	Media
ST/MONO/BP	ST/Mono/BP Tuner	SOUND DUAL	Dual

Original		Replacement	
BAND	Band Tuner	SEARCH TV/R	TV/R
ET TUNE	Preset Tune Up Tuner	+ CH	Ch +
PRESET	Preset Tune Down Tuner	CH −	Ch -
PRESET EQ	Preset EQ	SETTINGS OPT	Options
S-XBS	S-XBS	AD SUBT	Subt
TOP P CLOSE	Top Panel Close	FAV PRE-CH	Pre Ch
PANEL OPEN	Top Panel Open	GUIDE	Guide
UME +	Volume+	+ VOL	Vol +
− VOL	Volume-	VOL −	Vol -
SPATIALIZER	Spatializer	TIMER AV	AV

https://all-remote-controls.co.uk/en/Panasonic/1058925-85037-replacement-remote-control-for-Panasonic-RAK-RX416WH.html