Original		Replacement	
	Swap	LIST SMART	Smart / List
	Text	GOTO TEXT	Text / Goto
	Media	MEDIA DISPLAY	Display / Media
POWER	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
	Back	RETURN BACK	Back / Return
	FAV	PC FAV MARKER	Fav / Marker / PC

Original		Replacement	
	Subtitle	EQ SUBTITLE	Subtitle / EQ
	i	ANGLE INFO	Info / Angle
	V-Format	FORMAT PICTURE	Picture / Format
	Vol+	+ VOL	Vol+
	Page+	SHIFT + CH PAGE +	Shift + CH+ /
P+	P+	+ CH PAGE	CH+ / Page+
	Vol-	VOL −	Vol-
	Page-	SHIFT + CH PAGE −	Shift + CH- /
P-	P-	CH PAGE −	CH- / Page-
	Audio	LANG I/II AUDIO	Audio / Lang I/II
	AD	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II
	Sound / TV/Radio	TITLE SOUND	Sound / Title
	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right

Original		Replacement		Original	Replacement
MENU	Menu	HOME MENU	Menu / Home		
	Down		Down		
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
	Play	SLOW	Play / Slow		
	Pause	STEP-FREEZE	Pause / Step / Freeze		
	Stop	HOLD	Stop / Hold		
	Rec	REC MODE	Rec / Rec Mode		
	<<	TUNE-	<< / Tune-		
	>>	TUNE+	>> / Tune+		
	I<<	PRESET-	I<< / Preset-		
	>>I	PRESET+	>>I / Preset+		
TIMER	Timer	TIMER SLEEP	Sleep / Timer		
	Aspect	SIZE ZOOM	Zoom / Size		