Original		Replacement	
	Power		Power
	V- Mode	TOP MENU D.MENU	D. Menu / Top
	Mut e	DIMMER MUTE	Mut e / Di mmer
SAT	SAT	SHIFT + HDMI - SAT 0	Shi ft + 0
SAT	SAT	MEDIA DISPLAY	Di spl ay / Medi a
TV/AV	TV / AV	RDS AV INPUT	AV / I nput / RDS
ZOOM	Zoom	SIZE ZOOM	Zoom / Si ze
SLEEP	Sl eep	TIMER SLEEP	Sl eep / Ti mer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
PAUSE	Pause	STEP - FREEZE II	Pause / Step / Freeze
7	7	AUX - HDD 7	7

Original		Replacement	
8	8	USB 8	8
9	9	BLUETOOTH 9	9
PAGE+	Page +	SHIFT + CH PAGE +	Shi ft + CH+ /
TV/RADIO	TV / Radi o	PROGRAM TV/ RADIO	TV/ Radi o /
0	0	HDMI - SAT 0	0
←PR	<- PR	RETURN BACK	Back / Ret urn
PAGE-	Page -	SHIFT + CH PAGE −	Shi ft + CH- /
PR+	Up / PR +	CH PAGE +	CH+ / Page+
PR+	Up / PR +	▲	Up
	Left / Vol -	◀	Left
	Left / Vol -	VOL −	Vol -
OK LIST	OK / Li st	LIST SMART	Smart / Li st
OK LIST	OK / Li st	OK	OK
	Ri ght / Vol +	▶	Ri ght
	Ri ght / Vol +	VOL +	Vol +
PR-	Down / PR -	CH PAGE −	CH- / Page-
PR-	Down / PR -	▼	Down

Original		Replacement	
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
INFO	Info	ANGLE INFO	Info / Angle
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
FIND	Red / Find	NETFLIX SEARCH	Red / Netflix / Search
V-FORMAT	Green / V-Format	FORMAT PICTURE	Picture / Format
V-FORMAT	Green / V-Format	APP REPEAT	Green / APP / Repeat
TXT	Yellow / TXT	GOTO TEXT	Text / Goto
TXT	Yellow / TXT	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue / Audio	LANG I/II AUDIO	Audio / Lang I/II
	Blue / Audio	Prime Video RANDOM	Blue / Prime Video / Random
RECORD	Record	REC MODE	Rec / Rec Mode
PLAY	Play	SLOW	Play / Slow
STOP	Stop	HOLD	Stop / Hold
SHIFT	Shift	OPT-TOOLS SETUP	Setup / OPT /
FAST	<< Fast	TUNE-	<< / Tune-
FAST	>> Fast	TUNE+	>> / Tune+

Original		Replacement	
SLOW	< Slow	PRESET-	I<< / Preset-
SLOW	> Slow	PRESET+	>>I / Preset+