| Original | Replacement |
|---|---|
| VHS Power | Power |
| TV Power | Shift + Power |
| TV CH + | Shift + CH+ / |
| TV Volume + | Vol + |
| Audio | Audio / Lang I/II |
| TV AV | Shift + AV / Input / RDS |
| TV CH - | Shift + CH- / |
| TV Volume - | Vol - |
| Operation Select VHS | Smart / List |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| CH + / Tracking/V-Lock | CH+ / Page+ |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| CH - / Tracking/V-Lock | CH- / Page- |

| Original | Replacement |
|---|---|
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| Input | AV / Input / RDS |
| Cancel / Reset | Exit / Cancel / Clear |
| 0 | 0 |
| -/-- / ≧10 | Guide / EPG / -/-- |
| Repeat | Green / APP / Repeat |
| I<< Index/Skip | I<< / Preset- |
| >>I Index/Skip | >>I / Preset+ |
| << REW | << / Tune- |
| >> FF | >> / Tune+ |
| Stop | Stop / Hold |
| Pause / Slow | Pause / Step / Freeze |
| Play | Play / Slow |
| Up | Up |
| Menu / Play List | Menu / Home |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| | Left | | Left | | |
| ENTER | Enter | OK | OK | | |
| | Right | | Right | | |
| | Down | | Down | | |
| EXIT RETURN | Return / Exit | RETURN BACK | Back / Return | | |
| PROG/CHECK | Prog / Check | PROGRAM TV/RADIO | TV/Radio / | | |
| I-TIMER | i-Timer | NETFLIX SEARCH | Red / Netflix / Search | | |
| PLAY MODE PROG PLAY | Prog Play / Play Mode | TOP MENU D.MENU | D.Menu / Top | | |
| SETUP JET REW | << JET REW / | OPT-TOOLS SETUP | Setup / OPT / | | |
| TIMER | Timer | TIMER SLEEP | Sleep / Timer | | |
| DVD-RAM DUBBING | DVD-RAM | GOTO TEXT | Text / Goto | | |
| REC MODE | Rec Mode | SHIFT + REC MODE | Shift + Rec / Rec Mode | | |
| REC | Rec | REC MODE | Rec / Rec Mode | | |
| VHS STATUS DVD STATUS | VHS Status | ANGLE INFO | Info / Angle | | |
| CINEMA MODE A QUICK OSD | A / Cinema | YouTube REPEAT A-B | Yellow / YouTube / Repeat | | |
| OFF TIMER B QUICK REPLAY | B / Off Timer | Prime Video RANDOM | Blue / Prime Video / Random | | |
| EXT LINK MANUAL SKIP | Ext Link | MEDIA DISPLAY | Display / Media | | |

| Original | | Replacement | |
|---|---|---|---|
| VHS/DVD | DVD Power | | Power |
| TV | TV Power | SHIFT + | Shift + Power |
| CH | TV CH + | SHIFT + CH PAGE | Shift + CH+ / |
| VOLUME | TV Volume + | VOL | Vol + |
| AUDIO | Audio | LANG I/II AUDIO | Audio / Lang I/II |
| AV | TV AV | SHIFT + RDS AV INPUT | Shift + AV / Input / RDS |
| CH | TV CH - | SHIFT + CH PAGE | Shift + CH- / |
| VOLUME | TV Volume - | VOL | Vol - |
| OPERATION SELECT DVD | Operation Select DVD | LIST SMART | Smart / List |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |

| Original | | Replacement | |
|---|---|---|---|
| 9 | 9 | BLUETOOTH 9 | 9 |
| CANCEL/RESET | Cancel / Reset | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| 0 | 0 | HDMI-SAT 0 | 0 |
| ≧10 -/-- | -/-- / ≧10 | -/-- GUIDE EPG | Guide / EPG / -/-- |
| REPEAT | Repeat | APP REPEAT | Green / APP / Repeat |
| INDEX | I<< Index/Skip | PRESET- | I<< / Preset- |
| SKIP | >>I Index/Skip | PRESET+ | >>I / Preset+ |
| SLOW REW SEARCH | << REW | TUNE- | << / Tune- |
| SLOW / SEARCH FF | >> FF | TUNE+ | >> / Tune+ |
| STOP | Stop | HOLD | Stop / Hold |
| PAUSE SLOW | Pause / Slow | STEP-FREEZE | Pause / Step / Freeze |
| PLAY | Play | SLOW | Play / Slow |
| DIRECT NAVIGATOR TOP MENU | Direct Navigator Top Menu | TOP MENU D.MENU | D.Menu / Top |
| | Up | | Up |
| MENU PLAY LIST | Menu / Play List | HOME MENU | Menu / Home |
| | Left | | Left |
| ENTER | Enter | OK | OK |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| | Right | | Right | | |
| FUNCTIONS | Functions | MEDIA DISPLAY | Display / Media | | |
| | Down | | Down | | |
| EXIT RETURN | Return / Exit | RETURN BACK | Back / Return | | |
| SETUP JET REW | Setup | OPT-TOOLS SETUP | Setup / OPT / | | |
| DVD-RAM DUBBING | DVD-RAM | FORMAT PICTURE | Picture / Format | | |
| VHS STATUS DVD STATUS | DVD Status | ANGLE INFO | Info / Angle | | |
| CINEMA MODE A QUICK OSD | A / Quick OSD | YouTube REPEAT A-B | Yellow / YouTube / Repeat | | |
| OFF TIMER B QUICK REPLAY | B / Quick Replay | Prime Video RANDOM | Blue / Prime Video / Random | | |
| EXT LINK MANUAL SKIP | Manual Skip | GOTO TEXT | Text / Goto | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |