Mandis shop

# Philips 996580000768

| Original | Replacement |
|---|---|
| Power | Power |
| Coax | 1 |
| Optical | 3 |
| Aux | 4 |
| Audio In | 6 |
| USB | Guide |
| Bluetooth | 0 |
| HDMI ARC | Pre Ch |
| I< | I<< |
| Play/Pause | Play |
| I> | >>I |
| Bass+ | Up |
| Bass- | Down |
| Vol+ | Vol + |
| Vol- | Vol - |
| Mute | Mute |
| Treble+ | Ch + |

| Original | Replacement |
|---|---|
| Treble- | Ch - |
| Sound | Dual |
| Surround On | Smart |
| Surround Off | Media |
| Audio Sync + | Right |
| Audio Sync - | Left |
| Night | Info |
| DIM | D. Menu |

https://all-remote-controls.co.uk/en/Philips/1060282-24152-replacement-remote-control-for-Philips-996580000768.html