Original		Replacement	
	Power		Power
SOURCE	Source	TIMER AV	AV
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TTX/MIX	TTX/MIX	REPEAT TEXT	Text
PRE-CH	PRE-CH	FAV PRE-CH	Pre Ch
	Vol+	+ VOL	Vol +
	Vol-	VOL −	Vol -
MUTE	Mute	MUTE	Mute

Original		Replacement	
CH LIST	CH List	DISC NAV LIST	List
P	P+	+ CH	Ch +
P	P-	CH −	Ch -
MENU	Menu	TOP MENU MENU	Menu
	Smart Hub	HOME SMART	Smart
GUIDE	Guide	-/-- GUIDE	Guide
TOOLS	Tools	SETTINGS OPT	Options
INFO	Info	DISPLAY INFO	Info
RETURN	Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter	OK	Ok
A	Red	A	Red
B	Green	B	Green

Original		Replacement	
C	Yellow	C	Yellow
D	Blue	D	Blue
SEARCH	Search	SEARCH TV/R	TV/R
STATUS	Status	APP MEDIA	Media
AD/SUBT.	AD/Subt.	AD SUBT	Subt
E-MANUAL	E-Manual	E-MANUAL D.MENU	D. Menu
RECOMMEND	Recommend	PICTURE FORMAT	Format
3D	3D	ECO 3D	3D
<<	<<	<<	<<
I<<	I<<	I<<	I<<
Pause	Pause	Pause	Pause
>>	>>	>>	>>
>>I	>>I	>>I	>>I
Rec	Rec	REC MODE Rec	Rec
Play	Play	PLAY MODE Play	Play
Stop	Stop	Stop	Stop

Original	Replacement