Mandis shop

Sony RMSD70S

Original	Replacement
Power	Power
Sleep	Sleep
Disc Skip	Smart
Play CD	Play
Pause CD	Pause
Stop CD	Stop
Play	TV/R
I<</- Tuner/Band	I<<
>>I/+	>>I
Play Deck A	Red
<< Deck A	<<
>> Deck A	>>
Play Deck B	Green
Check	Options
Clear	Exit
Function	Menu
Loop	AV

Original	Replacement
Flash	Format
Up	Up
Down	Down
Right	Right
Left	Left
On/Off	Ok
Vol+	Vol +
Vol-	Vol -

https://all-remote-controls.co.uk/en/Sony/1060741-83073-replacement-remote-control-for-Sony-RMSD70S.html