| Original | | Replacement | |
|---|---|---|---|
| TV | TV | SEARCH TV/R | TV/R |
| CD | CD | C | Yellow |
| DVD | DVD | D | Blue |
| TUNER/ BAND | Tuner/Band | B | Green |
| TAPE | Tape | A | Red |
| VCR | VCR | HOME SMART | Smart |
| VOL + | Vol + | + VOL | Vol + |
| VOL - | Vol - | VOL - | Vol - |
| MUTING | Muting | MUTE | Mute |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| SELECT | Select | OK | Ok |
| MENU | Menu | E-MANUAL D.MENU | D. Menu |
| DISPLAY | Display | DISPLAY INFO | Info |
| DISC/DECK 1/2 | Disc/Deck 1/2 | TOP MENU MENU | Menu |

| Original | | Replacement | |
|---|---|---|---|
| TV/AV | Tv/AV | TIMER AV | AV |
| PRO LOGIC | Pro Logic | APP MEDIA | Media |
| CENTER - | Center- | SHIFT + CH - | Shift + Ch - |
| CENTER + | Center+ | SHIFT + CH + | Shift + Ch + |
| TEST | Test | RETURN BACK | Back |
| SURROUND + | Surround + | + CH | Ch + |
| SURROUND - | Surround - | CH - | Ch - |
| POWER | Power TV | | Power |
| VOL + | Tv Vol Up | SHIFT + + VOL | Shift + Vol + |
| TV VOL - | Tv Vol Down | SHIFT + VOL - | Shift + Vol - |
| 1 | 1 Tv | 1 | 1 |
| 2 | 2 Tv | 2 | 2 |
| 3 | 3 Tv | 3 | 3 |
| 4 | 4 Tv | 4 | 4 |
| 5 | 5 Tv | 5 | 5 |
| 6 | 6 Tv | 6 | 6 |
| 7 | 7 Tv | 7 | 7 |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| 8 | 8 Tv | 8 | 8 | | | | |
| 9 | 9 Tv | 9 | 9 | | | | |
| 0 | 0 Tv | 0 | 0 | | | | |
| ≥10/-/-- | >10/ - / - - Tv | -/-- GUIDE | Gui de | | | | |

| Original | | Replacement | |
|---|---|---|---|
| POWER | Power DVD | | Power |
| TV | TV | SEARCH TV/R | TV/R |
| VCR | VCR | HOME SMART | Smart |
| TUNER/ BAND | Tuner/Band | B | Green |
| TAPE | Tape | A | Red |
| CD | CD | C | Yellow |
| DVD | DVD | D | Blue |
| | Play DVD | PLAY MODE | Play |
| | I<</<< DVD | | << |
| | Stop DVD | | Stop |
| | >>/>>I DVD | | >> |
| DISC/DECK 1/2 | Disc/Deck 1/2 | TOP MENU MENU | Menu |
| DISPLAY | Display | DISPLAY INFO | Info |
| MENU | Menu | E-MANUAL D.MENU | D. Menu |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |

| Original | | Replacement | |
|---|---|---|---|
| | Left | | Left |
| SELECT | Select | OK | Ok |
| TEST | Test | RETURN BACK | Back |
| PRO LOGIC | Pro Logic | APP MEDIA | Media |
| – CENTER | Center- | SHIFT + CH – | Shift + Ch - |
| CENTER + | Center+ | SHIFT + CH + | Shift + Ch + |
| SURROUND + | Surround + | CH + | Ch + |
| – SURROUND | Surround - | CH – | Ch - |
| 1 | 1 DVD | 1 | 1 |
| 2 | 2 DVD | 2 | 2 |
| 3 | 3 DVD | 3 | 3 |
| 4 | 4 DVD | 4 | 4 |
| 5 | 5 DVD | 5 | 5 |
| 6 | 6 DVD | 6 | 6 |
| 7 | 7 DVD | 7 | 7 |
| 8 | 8 DVD | 8 | 8 |
| 9 | 9 DVD | 9 | 9 |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| 0 | 0 DVD | 0 | 0 | | | | |
| ≥10/-/-- | >10/- /- - DVD | -/-- GUIDE | Gui de | | | | |
| VOL + | Vol + | + VOL | Vol + | | | | |
| VO | Vol - | VOL − | Vol - | | | | |
| MUTING | Muti ng | MUTE | Mut e | | | | |

| Original | | Replacement | |
|---|---|---|---|
| POWER | Power CD | | Power |
| TV | TV | SEARCH TV/R | TV/R |
| VCR | VCR | HOME SMART | Smart |
| CD | CD | C | Yellow |
| DVD | DVD | D | Blue |
| TAPE | Tape | A | Red |
| TUNER/ BAND | Tuner/Band | B | Green |
| | Stop CD | | Stop |
| | I <</ << CD | | << |
| | >>/ >>I CD | | >> |
| | Play CD | PLAY MODE | Play |
| MENU | Menu | E-MANUAL D.MENU | D. Menu |
| DISPLAY | Display | DISPLAY INFO | Info |
| DISC/DECK 1/2 | Disc/Deck 1/2 | TOP MENU MENU | Menu |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |

| Original | | Replacement | |
|---|---|---|---|
| | Left | | Left |
| SELECT | Select | OK | Ok |
| TEST | Test | RETURN BACK | Back |
| PRO LOGIC | Pro Logic | APP MEDIA | Media |
| – CENT | Center- | SHIFT + CH – | Shift + Ch - |
| ENTER + | Center+ | SHIFT + CH + | Shift + Ch + |
| ROUND + | Surround + | + CH | Ch + |
| – SURRO | Surround - | CH – | Ch - |
| VOL + | Vol + | + VOL | Vol + |
| – VO | Vol - | VOL – | Vol - |
| MUTING | Muting | MUTE | Mute |
| POWER | Power Tape | SHIFT + | Shift + Power |
| | Stop Tape | SHIFT + | Shift + Stop |
| | Play Tape | SHIFT + PLAY MODE | Shift + Play |
| | I <</ << Tape | SHIFT + | Shift + << |
| | >>/ >>I Tape | SHIFT + | Shift + >> |
| DISC/DECK 1/2 | Disc/Deck 1/2 | SHIFT + TOP MENU MENU | Shift + Menu |

Tape

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| 1 | 1 CD- Tape | 1 | 1 | | | | |
| 2 | 2 CD- Tape | 2 | 2 | | | | |
| 3 | 3 CD- Tape | 3 | 3 | | | | |
| 4 | 4 CD- Tape | 4 | 4 | | | | |
| 5 | 5 CD- Tape | 5 | 5 | | | | |
| 6 | 6 CD- Tape | 6 | 6 | | | | |
| 7 | 7 CD- Tape | 7 | 7 | | | | |
| 8 | 8 CD- Tape | 8 | 8 | | | | |
| 9 | 9 CD- Tape | 9 | 9 | | | | |
| 0 | 0 CD- Tape | 0 | 0 | | | | |
| ≥10/-/-- | >10/ - / - - CD- Tape | -/-- GUIDE | Gui de | | | | |
| DIRECT TUNING/ DISC ENTER | Di rect Tuni ng/ Di sc Ente | REPEAT TEXT | Text | | | | |

| Original | | Replacement | |
|---|---|---|---|
| POWER | Power VCR | | Power |
| VCR | VCR | HOME SMART | Smart |
| TAPE | Tape | A | Red |
| TV | TV | SEARCH TV/R | TV/R |
| CD | CD | C | Yellow |
| DVD | DVD | D | Blue |
| TUNER/ BAND | Tuner/Band | B | Green |
| | Stop | | Stop |
| I<</<< | | << | |
| >>/>>I | | >> | |
| | Play | PLAY MODE | Play |
| 1 | 1 VCR | 1 | 1 |
| 2 | 2 VCR | 2 | 2 |
| 3 | 3 VCR | 3 | 3 |
| 4 | 4 VCR | 4 | 4 |
| 5 | 5 VCR | 5 | 5 |
| 6 | 6 VCR | 6 | 6 |

| Original | | Replacement | |
|---|---|---|---|
| 7 | 7 VCR | 7 | 7 |
| 8 | 8 VCR | 8 | 8 |
| 9 | 9 VCR | 9 | 9 |
| 0 | 0 VCR | 0 | 0 |
| ≥10/-/-- | >10/-/-- VCR | -/-- GUIDE | Guide |
| DIRECT TUNING/ DISC ENTER | Direct Tuning/Disc Ente | REPEAT TEXT | Text |
| VOL + | Vol + | + VOL | Vol + |
| VO - | Vol - | VOL - | Vol - |
| MUTING | Muting | MUTE | Mute |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| SELECT | Select | OK | Ok |
| DISC/DECK 1/2 | Disc/Deck 1/2 | TOP MENU MENU | Menu |
| DISPLAY | Display | DISPLAY INFO | Info |
| MENU | Menu | E-MANUAL D.MENU | D. Menu |

| Original | | Replacement | |
|---|---|---|---|
| TEST | Test | RETURN BACK | Back |
| PRO LOGIC | Pro Logic | APP MEDIA | Media |
| CENTER - | Center - | SHIFT + CH - | Shift + Ch - |
| CENTER + | Center + | SHIFT + CH + | Shift + Ch + |
| SURROUND + | Surround + | CH + | Ch + |
| SURROUND - | Surround - | CH - | Ch - |
| POWER | Power Tuner/Band | SHIFT + ⏻ | Shift + Power |
| 1 | 1 Tuner/Band | SHIFT + 1 | Shift + 1 |
| 2 | 2 Tuner/Band | SHIFT + 2 | Shift + 2 |
| 3 | 3 Tuner/Band | SHIFT + 3 | Shift + 3 |
| 4 | 4 Tuner/Band | SHIFT + 4 | Shift + 4 |
| 5 | 5 Tuner/Band | SHIFT + 5 | Shift + 5 |
| 6 | 6 Tuner/Band | SHIFT + 6 | Shift + 6 |
| 7 | 7 Tuner/Band | SHIFT + 7 | Shift + 7 |
| 8 | 8 Tuner/Band | SHIFT + 8 | Shift + 8 |
| 9 | 9 Tuner/Band | SHIFT + 9 | Shift + 9 |
| 0 | 0 Tuner/Band | SHIFT + 0 | Shift + 0 |

| Original | | Replacement | |
|---|---|---|---|
| ≥10/-/-- | >10/-/-- | SHIFT + -/-- GUIDE | Shift + Guide |