Mandis shop

RRMCG0144AWSA

Original	Replacement
On/Standby	Power
Vol+	Vol +
Vol-	Vol -
X-Bass/Equalizer	Smart
Video/AUX	Red
Tape (1↔2)	Blue
Tuner(Band)	Green
CD	Yellow
Rec/Pause Tape 2	Rec
<< Tape 2	<<
>> Tape 2	>>
Play Tape 2	Left
Play Tape 1	Right
Stop Tape	Ok
Tuner Preset Up	Ch +
Tuner Preset	Ch -
PTY TI	Back

Original	Replacement
Disc CD 1	1
Disc CD 2	2
Disc CD 3	3
Disc Skip	Media
I<<</<< CD	I<<
>>/>>I CD	>>I
Stop CD	Stop
Play CD	Play
Memory CD	3D
Clear	Exit
Random	TV/R
Pause CD	Pause

https://all-remote-controls.co.uk/en/Sharp/1061610-2982-replacement-remote-control-for-Sharp-RRMCG0144AWSA.html