Original		Replacement	
STANDBY	Standby		Power
OPEN/CLOSE	Open / Close	SURROUND	Eject / Surround
PLAY MODE	Play Mode	FORMAT PICTURE	Picture / Format
TIMER	Timer	TIMER SLEEP	Sleep / Timer
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
A - B	A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
TITLE	Title	TITLE SOUND	Sound / Title
DISPLAY	Display	MEDIA DISPLAY	Display / Media
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
MENU	Menu	HOME MENU	Menu / Home
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
RETURN	Return	RETURN BACK	Back / Return
WATCH TV	Watch TV	LIST SMART	Smart / List
	Up		Up
	Left		Left
SELECT	Select	OK	OK
	Right		Right

Original		Replacement	
	Down		Down
PLAY/PAUSE	Play / Pause	SLOW	Play / Slow
PLAY/PAUSE	Play / Pause	STEP - FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
SKIP	I<< Skip	PRESET-	I<< / Preset-
SKIP	Skip >>I	PRESET+	>>I / Preset+
SEARCH	<< Search	TUNE-	<< / Tune-
SEARCH	Search >>	TUNE+	>> / Tune+
PROGRAM	Program+	CH PAGE	CH+ / Page+
REC. MODE	Rec. Mode	SHIFT + REC MODE	Shift + Rec / Rec Mode
TV/DVD	TV / DVD	PROGRAM TV/ RADIO	TV/Radio /
PROGRAM	Program-	CH PAGE	CH- / Page-
RECORD	Record	REC MODE	Rec / Rec Mode
INSERT CHAPTER	Insert Chapter	TOP MENU D.MENU	D.Menu / Top
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
VIDEO SOURCE	Video Source	RDS AV INPUT	AV / Input / RDS
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II

Original		Replacement	
ANGLE	Angle	ANGLE INFO	Info / Angle
SEARCH MODE	Search Mode	NETFLIX SEARCH	Red / Netflix / Search
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0

Original	Replacement