| Original | | Replacement | |
|---|---|---|---|
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD - STB 3 | 3 |
| POW ON | Power On | | Power |
| WER OFF | Power Off | SHIFT + | Shift + Power |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| CH | CH+ | CH PAGE + | CH+ / Page+ |
| VOL + | Vol + | VOL + | Vol + |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| CH | CH- | CH PAGE - | CH- / Page- |
| VOL - | Vol - | VOL - | Vol - |
| +10 | +10 | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 0 | 0 | HDMI - SAT 0 | 0 |

| Original | | Replacement | |
|---|---|---|---|
| MEM X | Memory | PC FAV MARKER | Fav / Marker / PC |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| FRQ DIRECT | FRQ Direct | SLOW | Play / Slow |
| GUIDE C CTR | Center | TIMER SLEEP | Sleep / Timer |
| | Up | | Up |
| MENU M OSD | Menu | HOME MENU | Menu / Home |
| TUNE | Tune | PRESET- | I<< / Preset- |
| PRESET | Preset | PRESET+ | >>I / Preset+ |
| - | -/Back | | Left |
| ENT | Enter | OK | OK |
| + | +/Forward | | Right |
| FM MONO | FM Mono | STEP - FREEZE | Pause / Step / Freeze |
| BAND | Band | HOLD | Stop / Hold |
| SEARCH- S SUB | Swoofer | EQ SUBTITLE | Subtitle / EQ |
| | Down | | Down |
| SEARCH+ R SUR | Surround | SURROUND | Eject / Surround |
| DISC1 EQ | EQ | SHIFT + EQ SUBTITLE | Shift + Subtitle / EQ |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| DISC2 DYN | DYN | TITLE SOUND | Sound / Title | V4 | V4 | SHIFT + | Prime Video RANDOM — Shift + Blue / Prime |
| DISC3 REC | Rec | REC MODE | Rec / Rec Mode | V5 | V5 | SHIFT + | PC FAV MARKER — Shift + Fav / Marker / PC |
| DISC4 ZONE | Zone | TUNE- | << / Tune- | DISPLAY DISP | Display | MEDIA DISPLAY | Display / Media |
| DISC5 SUR+ | Sur+ | SHIFT + | SURROUND — Shift + Eject / Surround | AUDIO TAPE2 | Tape 2 | SHIFT + | TV 1 — Shift + 1 |
| CD | CD | SHIFT + | CD-STB 3 — Shift + 3 | ANGLE PHONO | Phono | SHIFT + | VIDEO 4 — Shift + 4 |
| TUN | Tun | SHIFT + | TUNER 6 — Shift + 6 | SBTITLE TONE | Tone | GOTO TEXT | Text / Goto |
| TAPE | Tape | SHIFT + | TAPE 5 — Shift + 5 | ZOOM D-SLT | D-SLT | TOP MENU D.MENU | D.Menu / Top |
| EXT | EXT | RDS AV INPUT | AV / Input / RDS | RESUME SCAN INPUT 1 | Scan | TUNE+ | >> / Tune+ |
| PROG 2CH | 2 CH | LANG I/II AUDIO | Audio / Lang I/II | REPEAT PTY INPUT 2 | PTY | ANGLE INFO | Info / Angle |
| RANDOM PL C DIGEST | PL C | NETFLIX SEARCH | Red / Netflix / Search | A-B P-TUN INPUT 3 | P-Tun | PROGRAM TV/ RADIO | TV/ Radio / |
| REPEAT PL M TITLE | PL M | APP REPEAT | Green / APP / Repeat | GOTO TP TV/VCR | TP | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| DISC- 5CH P-SCAN | 5 CH | YouTube REPEAT A-B | Yellow / YouTube / Repeat | SLOW TA RECORD | TA | RETURN BACK | Back / Return |
| DISC+ 7CH OPEN | 7 CH | Prime Video RANDOM | Blue / Prime Video / Random | ASPECT | Aspect | FORMAT PICTURE | Picture / Format |
| V1 | V1/ DVD | SHIFT + | NETFLIX SEARCH — Shift + Red / Netflix / | DISP | Disp | SHIFT + | MEDIA DISPLAY — Shift + Display / Media |
| V1 | V1/ DVD | SHIFT + | DVD 2 — Shift + 2 | PIP | PIP | OPT-TOOLS SETUP | Setup / OPT / |
| V2 | V2 | SHIFT + | APP REPEAT — Shift + Green / APP / | POP | POP | SIZE ZOOM | Zoom / Size |
| V3 | V3 | SHIFT + | YouTube REPEAT A-B — Shift + Yellow / YouTube / Repeat | OUTPUT | Output | LIST SMART | Smart / List |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| POWER Power | SHIFT + OK Shift + OK | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| 1 | 1 | Play | Play / Slow |
| 2 | 2 | Menu | Menu / Home |
| 3 | 3 | Up | Up |
| Power On | Power | OSD | Smart / List |
| Power Off | Shift + Power | I << | I << / Preset- |
| 4 | 4 | >>I | >>I / Preset+ |
| 5 | 5 | - / Back | << / Tune- |
| 6 | 6 | - / Back | Left |
| Vol + | Vol + | Enter | OK |
| 7 | 7 | +/ Forward | >> / Tune+ |
| 8 | 8 | +/ Forward | Right |
| 9 | 9 | Pause | Pause / Step / Freeze |
| Vol - | Vol - | Stop | Stop / Hold |
| Ten (+10) | Guide / EPG / -/-- | Search- | CH- / Page- |
| 0 | 0 | Down | Down |
| Clear (X) | Exit / Cancel / Clear | Search+ | CH+ / Page+ |
| Mute | Mute / Dimmer | Random (DYN) | Blue / Prime Video / Random |

| Original | | Replacement | |
|---|---|---|---|
| DISC3 REC | PAL (Rec) | TOP MENU D.MENU | D. Menu / Top |
| DISC4 ZONE | HD Mode | OPT-TOOLS SETUP | Setup / OPT / |
| DISC5 SUR+ | DIM (SUR+) | SHIFT + DIMMER MUTE | Shift + Mute / Dimmer |
| PROG 2CH | Prog (2CH) | RDS AV INPUT | AV / Input / RDS |
| RANDOM PL C DIGEST | Screen (PL C) | FORMAT PICTURE | Picture / Format |
| REPEAT PL M TITLE | Title (PL M) | TITLE SOUND | Sound / Title |
| REPEAT PL M TITLE | Repeat | APP REPEAT | Green / APP / Repeat |
| DISC- 5CH P-SCAN | Prog-Scan | PROGRAM TV/RADIO | TV/Radio / |
| DISC+ 7CH OPEN | Open (7CH) | SURROUND ⏏ | Eject / Surround |
| DISPLAY DISP | Display | MEDIA DISPLAY | Display / Media |
| AUDIO TAPE2 | Audio | LANG I/II AUDIO | Audio / Lang I/II |
| ANGLE PHONO | Angle | ANGLE INFO | Info / Angle |
| SBTITLE TONE | Subtitle | EQ SUBTITLE | Subtitle / EQ |
| ZOOM D-SLT | Zoom | SIZE ZOOM | Zoom / Size |
| RESUME SCAN INPUT 1 | Resume | RETURN BACK | Back / Return |
| A-B P-TUN INPUT 3 | A-B | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| GOTO TP TV/VCR | Goto | GOTO TEXT | Text / Goto |

| Original | | Replacement | |
|---|---|---|---|
| SLOW TA RECORD | Slow | SHIFT + SLOW ▶ | Shift + Play / |
| POWER | Power | SHIFT + OK | Shift + OK |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| 1 | 1 | I << | I << / Preset- |
| 2 | 2 | >>I | >>I / Preset+ |
| 3 | 3 | Open (ENT) | OK |
| Power On | Power | Open (ENT) | Eject / Surround |
| Power Off | Shift + Power | Pause | Pause / Step / Freeze |
| 4 | 4 | Stop | Stop / Hold |
| 5 | 5 | Search- | CH- / Page- |
| 6 | 6 | Search+ | CH+ / Page+ |
| Vol + | Vol + | Disc 1 | Shift + 1 |
| 7 | 7 | Disc 2 | Shift + 2 |
| 8 | 8 | Disc 3 | Shift + 3 |
| 9 | 9 | Disc 4 | Shift + 4 |
| Vol - | Vol - | Disc 5 | Shift + 5 |
| TEN (+10) | Guide / EPG / -/-- | Program (2CH) | TV/ Radio / |
| 0 | 0 | Random (PL C) | Blue / Prime Video / Random |
| Mute | Mute / Dimmer | Repeat (PL M) | Green / APP / Repeat |
| Play | Play / Slow | Disc+ (7CH) | Subtitle / EQ |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| DISPLAY DISP | Display (DISP | MEDIA DISPLAY | Display / Media | | |
| RESUME SCAN INPUT 1 | Scan | TUNE+ ▶▶ | >> / Tune+ | | |
| REPEAT PTY INPUT 2 | Time (PTY) | TIMER SLEEP | Sleep / Timer | | |
| A-B P-TUN INPUT 3 | A-B (P-Tun) | YouTube REPEAT A-B | Yellow / YouTube / Repeat | | |
| GOTO TP TV/VCR | Review (TP) | TUNE- ◀◀ | << / Tune- | | |
| SLOW TA RECORD | Clear (TA) | TOP MENU D.MENU | D.Menu / Top | | |
| POWER | Power | SHIFT + OK | Shift + OK | | |