| Original | | Replacement | |
|---|---|---|---|
| Power | Power | Power | Power |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD - STB 3 | 3 |
| Mute | Mute | DIMMER MUTE | Mute / Dimmer |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| RECALL | Recall | RETURN BACK | Back / Return |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| 0 | 0 | HDMI - SAT 0 | 0 |
| MENU | Menu | HOME MENU | Menu / Home |
| CH+ | Up | | Up |
| CH+ | CH+ | + CH PAGE | CH+ / Page+ |
| EXIT | Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |

| Original | | Replacement | |
|---|---|---|---|
| VOL- | Left | | Left |
| VOL- | Vol- | VOL − | Vol- |
| OK | OK | OK | OK |
| VOL+ | Right | | Right |
| VOL+ | Vol+ | + VOL | Vol+ |
| Pg Up | Pg Up | SHIFT + + CH PAGE | Shift + CH+ / |
| CH- | Down | | Down |
| CH- | CH- | CH PAGE − | CH- / Page- |
| Pg Dn | Pg Dn | SHIFT + CH PAGE − | Shift + CH- / |
| TV/RADIO | Tv/Radio | PROGRAM TV/ RADIO | TV/Radio / |
| INFO | Info | ANGLE INFO | Info / Angle |
| FAV | FAV | PC FAV MARKER | Fav / Marker / PC |
| AUDIO | Audio | LANG I/II AUDIO | Audio / Lang I/II |
| SUB-T | Sub-T | EQ SUBTITLE | Subtitle / EQ |
| TTX | TTX | GOTO TEXT | Text / Goto |
| EPG | EPG | -/-- GUIDE EPG | Guide / EPG / -/-- |
| | Play | SLOW | Play / Slow |

| Original | | Replacement | |
|---|---|---|---|
| | Pause | STEP-FREEZE | Pause / Step / Freeze |
| | Stop | HOLD | Stop / Hold |
| | Rec | REC MODE | Rec / Rec Mode |
| | Red/<< | NETFLIX SEARCH | Red / Netflix / Search |
| | Green/>> | APP REPEAT | Green / APP / Repeat |
| | Yellow | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| PVR | Blue/PVR | Prime Video RANDOM | Blue / Prime Video / Random |

| Original | Replacement |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |