Original		Replacement	
Power		Power	
Input Selector		AV	
FM/AM		SHIFT + 1	Shift + 1
TV		SHIFT + 2	Shift + 2
DVD Recorder		SHIFT + 3	Shift + 3
PLAYER BD/DVD	BD/DVD Player / Analog 8CH	SHIFT + 4	Shift + 4
CABLE SAT	Cable / Sat	SHIFT + 5	Shift + 5
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0

Original		Replacement	
≥10	>10	GUIDE	Guide
DIRECT TUNING	Direct Tuning	OK	Ok
CH	CH+	CH	Ch +
CH	CH+		Up
CH	CH-		Down
CH	CH-	CH	Ch -
VOL	Vol +	VOL	Vol +
VOL	Vol -	VOL	Vol -
MUTING	Muting	MUTE	Mute
DRIVE SELECT	Drive Select	MEDIA	Media
	Tune-		Left
	<< PORT		<<
	Tune+		Right
	>> PORT		>>
STOP	Stop PORT		Stop
PAUSE	Pause PORT		Pause
PLAY	Play PORT	PLAY MODE	Play

Original	Replacement	Original	Replacement
I << PORT	I <<		
>>I PORT	>>I		
One Touch Play	Smart		
Surround Off	Shift + Red		
PL IIx	Red		
NEO: 6	Green		
SFC Music	Yellow		
SFC Movie	Blue		
Test / Auto	Text		
Sound Menu	Dual		
Display	Info		
Option Port /	Options		
TV Vol +	Shift + Vol +		
TV Vol -	Shift + Vol -		
TV/Video	TV/R		

Original		Replacement	
Power		Power	
Input Selector		AV	
FM/AM		SHIFT + 1	Shift + 1
DVD Power		SHIFT + Power	Shift + Power
TV		SHIFT + 2	Shift + 2
DVD Recorder		SHIFT + 3	Shift + 3
BD/DVD Player / Analog 8CH		SHIFT + 4	Shift + 4
Cable / Sat		SHIFT + 5	Shift + 5
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	

Original		Replacement	
0		0	
>10		GUIDE	
CH+		CH +	
CH-		CH -	
Vol +		Vol +	
Vol -		Vol -	
Muting		Mute	
Drive Select		MEDIA	
<<		<<	
>>		>>	
Stop		Stop	
Pause		Pause	
Play		Play	
I <<		I <<	
>>I		>>I	
One Touch Play		SMART	
Top Menu / Direct Navigator		LIST	

Original		Replacement	
FUNCTIONS	Functions DVD Recorder	SHIFT + TOP MENU / MENU	Shift + Menu
FUNCTIONS	Functions DVD Player	TOP MENU / MENU	Menu
▲	Up	▲	Up
◀	Left	◀	Left
OK	OK	OK	Ok
▶	Right	▶	Right
▼	Down	▼	Down
SUB MENU / S	Sub Menu	E-MANUAL / D.MENU	D. Menu
RETURN	Return	RETURN / BACK	Back
SURROUND / OFF	Surround Off	SHIFT + A	Shift + Red
PLIIx	PL IIx	A	Red
NEO:6	NEO: 6	B	Green
MUSIC	SFC Music	C	Yellow
MOVIE	SFC Movie	D	Blue
AUTO / TEST	Test / Auto	REPEAT / TEXT	Text
SOUND / MENU	Sound Menu	SOUND / DUAL	Dual
DISPLAY	Display	DISPLAY / INFO	Info

Original		Replacement	
OPTION / PORT	Option Port /	SETTINGS / OPT	Options
+ / VOL	TV Vol +	SHIFT + + / CH	Shift + Ch +
VOL / −	TV Vol -	SHIFT + CH / −	Shift + Ch -
TV/VIDEO	TV/Video	SEARCH / TV/R	TV/R

Original		Replacement	
	Power		Power
INPUT SELECTOR	Input Selector	TIMER AV	AV
FM/AM	FM/AM	SHIFT + 1	Shift + 1
AV SYSTEM	TV Power	SHIFT +	Shift + Power
TV	TV	SHIFT + 2	Shift + 2
RECORDER DVD	DVD Recorder	SHIFT + 3	Shift + 3
PLAYER BD/DVD	BD/DVD Player / Analog 8CH	SHIFT + 4	Shift + 4
CABLE SAT	Cable / Sat	SHIFT + 5	Shift + 5
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9

Original		Replacement	
0	0	0	0
≥10	>10	GUIDE	Guide
CH	CH+	CH	Ch +
CH	CH-	CH	Ch -
VOL	Vol +	VOL	Vol +
VOL	Vol -	VOL	Vol -
MUTING	Muting	MUTE	Mute
DRIVE SELECT	Drive Select	APP MEDIA	Media
ONE TOUCH PLAY	One Touch Play	HOME SMART	Smart
FUNCTIONS	Functions	TOP MENU MENU	Menu
▲	Up	▲	Up
◀	Left	◀	Left
OK	OK	OK	Ok
▶	Right	▶	Right
▼	Down	▼	Down
SUB MENU S	Sub Menu	E-MANUAL D.MENU	D. Menu
RETURN	Return	RETURN BACK	Back

Original		Replacement		Original	Replacement
SURROUND OFF	Surround Off	SHIFT + A	Shift + Red		
PL IIx	PL IIx	A	Red		
NEO:6	NEO: 6	B	Green		
MUSIC	SFC Music	C	Yellow		
MOVIE	SFC Movie	D	Blue		
AUTO TEST	Test / Auto	REPEAT TEXT	Text		
SOUND MENU	Sound Menu	SOUND DUAL	Dual		
DISPLAY	Display	DISPLAY INFO	Info		
OPTION PORT	Option Port /	SETTINGS OPT	Options		
VOL +	TV Vol +	SHIFT + CH +	Shift + Ch +		
VOL −	TV Vol -	SHIFT + CH −	Shift + Ch -		
TV/VIDEO	TV/Video	SEARCH TV/R	TV/R		

Original		Replacement	
	Power		Power
INPUT SELECTOR	Input Selector	TIMER AV	AV
FM/AM	FM/AM	SHIFT + 1	Shift + 1
AV SYSTEM	Power	SHIFT +	Shift + Power
TV	TV	SHIFT + 2	Shift + 2
RECORDER DVD	DVD Recorder	SHIFT + 3	Shift + 3
PLAYER BD/DVD	BD/DVD Player / Analog 8CH	SHIFT + 4	Shift + 4
CABLE SAT	Cable / Sat	SHIFT + 5	Shift + 5
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9

Original		Replacement	
0	0	0	0
CH	CH+	CH	Ch +
CH	CH-	CH	Ch -
VOL	Vol +	VOL	Vol +
VOL	Vol -	VOL	Vol -
MUTING	Muting	MUTE	Mute
DRIVE SELECT	Drive Select	APP MEDIA	Media
ONE TOUCH PLAY	One Touch Play	HOME SMART	Smart
SURROUND OFF	Surround Off	SHIFT + A	Shift + Red
PLIIx	PL IIx	A	Red
NEO:6	NEO: 6	B	Green
MUSIC	SFC Music	C	Yellow
MOVIE	SFC Movie	D	Blue
AUTO TEST	Test / Auto	REPEAT TEXT	Text
SOUND MENU	Sound Menu	SOUND DUAL	Dual
DISPLAY	Display	DISPLAY INFO	Info
OPTION PORT	Option Port / Setup	SETTINGS OPT	Options

Original	Replacement	Original	Replacement
VOL + TV Vol +	SHIFT + CH + Shift + Ch +		
VOL − TV Vol -	SHIFT + CH − Shift + Ch -		
TV/VIDEO TV/ Video	SEARCH TV/R TV/ R		