Mandis shop

RM-S616

Original		Replacement	
POWER	Power		Power
CD	CD	C	Yellow
I<< CD	I<<		I<<
>>I CD	>>I		>>I
Play CD	Play	PLAY MODE	Play
Stop CD	Stop		Stop
TAPE	Tape	D	Blue
<< Deck A	<< Deck A		Down
<< Deck B	<< Deck B	SHIFT +	Shift + Down
>> Deck A	>> Deck A		Up
>> Deck B	>> Deck B	SHIFT +	Shift + Up
< Deck A	< Deck A		Left
< Deck B	< Deck B	SHIFT +	Shift + Left
>Deck A	>Deck A		Right
> Deck B	> Deck B	SHIFT +	Shift + Right
Stop Deck A	Stop Deck A	OK	Ok
Stop Deck B	Stop Deck B	SHIFT + OK	Shift + Ok

Original		Replacement	
	Rec Deck B	SHIFT + REC MODE	Shift + Rec
	Pause Deck B	SHIFT +	Shift + Pause
	Stop Rec Deck	SHIFT +	Shift + Stop
TUNER	Tuner	A	Red
PRESET +	Preset+	CH +	Ch +
PRESET −	Preset-	CH −	Ch -
PHONO	Phono	B	Green
VOL +	Vol+	VOL +	Vol +
VOL −	Vol-	VOL −	Vol -

https://all-remote-controls.co.uk/en/Sony/1064290-94819-replacement-remote-control-for-Sony-RM-S616.html