Original		Replacement	
	Power		Power
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
TTX/MIX	TTX/MIX	GOTO TEXT	Text / Goto
PRE-CH	PRE-CH	PC FAV MARKER	Fav / Marker / PC
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
CH LIST	CH LIST	LIST SMART	Smart / List
+ VOL	Vol+	+ VOL	Vol+

Original		Replacement	
VOL –	Vol-	VOL –	Vol-
CH	Ch+	+ CH PAGE	CH+ / Page+
CH	Ch-	CH PAGE –	CH- / Page-
SETTINGS	Settings	OPT-TOOLS SETUP	Setup / OPT /
	Home	HOME MENU	Menu / Home
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
INFO	Info	ANGLE INFO	Info / Angle
E-MANUAL	E-Manual	TOP MENU D.MENU	D.Menu / Top
	Up		Up
	Down		Down
	Left		Left
	Right		Right
	Enter	OK	OK
RETURN	Return	RETURN BACK	Back / Return
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
A	Red	NETFLIX SEARCH	Red / Netflix / Search
B	Green	APP REPEAT	Green / APP / Repeat

Original		Replacement	
C	Yellow	YouTube / REPEAT A-B	Yellow / YouTube / Repeat
D	Blue	Prime Video / RANDOM	Blue / Prime Video / Random
PIC SIZE	Pic Size	SIZE / ZOOM	Zoom / Size
PICTURE	Picture	FORMAT / PICTURE	Picture / Format
AD/SUBT.	Ad/Subt.	EQ / SUBTITLE	Subtitle / EQ
■	Stop	HOLD / ■	Stop / Hold
⏮	<<|<<	TUNE- / ◀◀	<< / Tune-
▶	Play	SLOW / ▶	Play / Slow
⏸	Pause	STEP-FREEZE / ⏸	Pause / Step / Freeze
⏭	>>/>>|	TUNE+ / ▶▶	>> / Tune+

Original	Replacement