Mandis shop

Sony RM-SC55

Original		Replacement	
I / ⏻	Power		Power
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
DISPLAY	Display	MEDIA DISPLAY	Display / Media
TUNER MEMORY	Tuner Memory	SIZE ZOOM	Zoom / Size
PLAY MODE/ TUNING MODE	Play Mode/Tuning Mode	PROGRAM TV/ RADIO	TV/Radio /
–	Folder-	CH PAGE –	CH- / Page-
REPEAT/ FM MODE	Repeat/FM	FORMAT PICTURE	Picture / Format
SELECT	Clock/Timer		Up
SET	Clock/Timer Set		Down
AUDIO IN	Audio In	LANG I/II AUDIO	Audio / Lang I/II
CD	CD	CD - STB 3	3
TUNER BAND	Band/Tuner	SHIFT + PROGRAM TV/ RADIO	Shift + TV/Radio / Program
FUNCTION	Function	TOP MENU D.MENU	D.Menu / Top
–	I<</-	PRESET-	I<< / Preset-
+	>>I/+	PRESET+	>>I / Preset+
←	<</←	TUNE-	<< / Tune-
→	>>/→	TUNE+	>> / Tune+

Original		Replacement	
▶	Play	SLOW ▶	Play / Slow
⏸	Pause	STEP - FREEZE ⏸	Pause / Step / Freeze
■	Stop	HOLD ■	Stop / Hold
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
EQ	EQ	EQ SUBTITLE	Subtitle / EQ
+ VOLUME	Vol+	+ VOL	Vol+
– VOLUME	Vol-	VOL –	Vol-
ENTER	Enter	OK	OK
DISC SKIP	Disck Skip	PC FAV MARKER	Fav / Marker / PC
+	Folder+	+ CH PAGE	CH+ / Page+

https://all-remote-controls.co.uk/en/Sony/1065500-79577-replacement-remote-control-for-Sony-RM-SC55-A1169936A.html