Original	Replacement	Original	Replacement
Standby / On	Power	Next / Fwd	>> / Tune+
Title	Sound / Title	Next / Fwd	>>I / Preset+
Menu	Menu / Home	0	0
Open / Close	Eject / Surround	Clear	Exit / Cancel / Clear
OSD / Setup	Setup / OPT /	Search	Red / Netflix / Search
1	1	Pause / Step	Pause / Step / Freeze
2	2	Up	Up
3	3	Play	Play / Slow
Slow Fwd	Shift + Play /	Left	Left
4	4	Enter	OK
5	5	Right	Right
6	6	Stop	Stop / Hold
Prev / Rev	<< / Tune-	Down	Down
Prev / Rev	I<< / Preset-	Return	Back / Return
7	7	Play Mode	Display / Media
8	8	A-B	Yellow / YouTube / Repeat
9	9	Memory	Fav / Marker / PC

Original		Replacement		Original	Replacement
TIMER	Timer	TIMER SLEEP	Sleep / Timer		
EQUALIZER	Equalizer	SHIFT + EQ SUBTITLE	Shift + Subtitle / EQ		
VOL/CH	Vol / CH	LIST SMART	Smart / List		
	empty left	CH PAGE −	CH- / Page-		
	empty right	+ CH PAGE	CH+ / Page+		
ZOOM	Zoom	SIZE ZOOM	Zoom / Size		
ANGLE	Angle	ANGLE INFO	Info / Angle		
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ		
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II		