Mandis shop

# MAJESTIC HTS 511 OPT

| Original | Replacement |
|---|---|
| Standby | Power |
| INPUT OPTIC | 3 |
| INPUT COAX | 2 |
| INPUT AUX | 1 |
| INPUT AUX | 7 |
| Volume+ | Up |
| Volume+ | Vol+ |
| SUB- | Left |
| Mute | Mute / Dimmer |
| Mute | OK |
| SUB+ | Right |
| Volume- | Down |
| Volume- | Vol- |
| Center- | CH- / Page- |
| Center+ | CH+ / Page+ |
| Surrounds L- | << / Tune- |
| Surrounds L+ | >> / Tune+ |

| Original | Replacement |
|---|---|
| Surrounds R- | I<< / Preset- |
| Surrounds R+ | >>I / Preset+ |

https://all-remote-controls.co.uk/en/MAJESTIC/1066001-93998-replacement-remote-control-for-MAJESTIC-HTS-511-OPT.html