Original		Replacement	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
	TV / Radio	PROGRAM TV/ RADIO	TV/Radio /
	Subtitle	EQ SUBTITLE	Subtitle / EQ
	Text	GOTO TEXT	Text / Goto
HD/SD	HD / SD	MEDIA DISPLAY	Display / Media
1	1	TV 1	1
2 ABC	2	DVD 2	2
3 DEF	3	CD - STB 3	3
4 GHI	4	VIDEO 4	4
5 JKL	5	TAPE 5	5
6 MNO	6	TUNER 6	6
7 PQRS	7	AUX - HDD 7	7
8 TUV	8	USB 8	8
9 WXYZ	9	BLUETOOTH 9	9
BACK	Back	RETURN BACK	Back / Return
0	0	HDMI - SAT 0	0

Original		Replacement	
AV	AV	RDS AV INPUT	AV / Input / RDS
VOL	Vol+	VOL	Vol+
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
CH	CH+	CH PAGE	CH+ / Page+
VOL	Vol-	VOL	Vol-
	Up		Up
CH	CH-	CH PAGE	CH- / Page-
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
	Home	TOP MENU D.MENU	D.Menu / Top
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
LIST	List	LIST SMART	Smart / List
FAV	Fav	PC FAV MARKER	Fav / Marker / PC
	Dual Screen	OPT-TOOLS SETUP	Setup / OPT / Tools

Original	Replacement	Original	Replacement
i	Info / Angle		
Red / Stop	Red / Netflix / Search		
Red / Stop	Stop / Hold		
Green /	Green / APP / Repeat		
Green /	Pause / Step / Freeze		
Green /	Play / Slow		
Yellow / <<	<< / Tune-		
Yellow / <<	Yellow / YouTube / Repeat		
Blue / >>	>> / Tune+		
Blue / >>	Blue / Prime Video / Random		
APP	Shift + Green / APP /		
Format	Picture / Format		
Timer	Sleep / Timer		
Audio ?	Audio / Lang I/II		