Mandis shop

Sharp RRMCG0106AWSA

Original		Replacement	
ON/STAND-BY	On/Standby		Power
	Stop	HOLD	Stop / Hold
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
/RANDOM	Back/Random	RETURN BACK	Back / Return
PRES	I<</<</Preset	PRESET-	I<< / Preset-
RESET	Preset Up/>>/>>I	PRESET+	>>I / Preset+
MEMORY/SET	Memory/Set	HOME MENU	Menu / Home
TUNIN	Tuning-	TUNE-	<< / Tune-
UNING	Tuning+	TUNE+	>> / Tune+
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
TIMER/SET	Timer Set	TOP MENU D.MENU	D.Menu / Top
TIMER	Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
TIME	Timer Down		Down
IMER	Timer Up		Up
FUNCTION	Function	OPT-TOOLS SETUP	Setup / OPT / Tools

Original		Replacement	
BAND	Band	PROGRAM TV/RADIO	TV/Radio /
X-BASS/ EQUALIZER	X-Bass/Equalizer	LANG I/II AUDIO	Audio / Lang I/II
VOLU	Vol-	VOL	Vol-
LUME	Vol+	VOL	Vol+

https://all-remote-controls.co.uk/en/Sharp/1066113-2457-replacement-remote-control-for-Sharp-RRMCG0106AWSA.html