Mandis shop

BOM003

Original		Replacement		Original	Replacement
PROGRAM	Program	PROGRAM TV/ RADIO	TV/Radio /		
−10/FOL−	-10/Fol-	CH PAGE −	CH- / Page-		
+10/FOL+	+10/Fol+	+ CH PAGE	CH+ / Page+		
▶/II/USB	Play USB	SLOW ▶	Play / Slow		
▶/II/USB	Pause USB	STEP · FREEZE II	Pause / Step / Freeze		
I<<	I<<	PRESET- I◀◀	I<< / Preset-		
<<	<<	TUNE- ◀◀	<< / Tune-		
>>	>>	TUNE+ ▶▶	>> / Tune+		
>>I	>>I	PRESET+ ▶▶I	>>I / Preset+		
STOP	Stop	HOLD ■	Stop / Hold		
REPEAT/RANDOM	Repeat/Random	APP REPEAT	Green / APP / Repeat		
VOL−	Vol-	VOL −	Vol-		
VOL+	Vol+	+ VOL	Vol+		

https://all-remote-controls.co.uk/en/BOMAN/1066556-91148-replacement-remote-control-for-BOMAN-BOM003.html