Mandis shop

CU-XR005

| Original | Replacement |
|---|---|
| Power | Power |
| Volume- | Vol- |
| Volume+ | Vol+ |
| Function | Menu / Home |
| SFC Preset | Smart / List |
| Smart Ope. | Display / Media |
| Scan | Back / Return |
| Tuner Station- | CH- / Page- |
| Tuner Station+ | CH+ / Page+ |
| Stop Deck II | Shift + OK |
| Stop Deck | OK |
| < Deck II | Shift + Left |
| < Deck | Left |
| Deck II > | Right |
| > Deck | Shift + Right |
| Rec/Pause Deck II | Rec / Rec Mode |
| << Deck II | Shift + << / Tune- |

| Original | Replacement |
|---|---|
| << Deck | << / Tune- |
| >> Deck II | Shift + >> / |
| >> Deck | >> / Tune+ |
| Random | Blue / Prime Video / Random |
| Play CD | Play / Slow |
| Sleep | Sleep / Timer |
| I<< CD | I<< / Preset- |
| >>I CD | >>I / Preset+ |
| Snooze | Info / Angle |
| Pause CD | Pause / Step / Freeze |
| Stop CD | Stop / Hold |

https://all-remote-controls.co.uk/en/Pioneer/1066817-91362-replacement-remote-control-for-Pioneer-CU-XR005.html