Mandis shop

Aiwa RC-TN520EX

Original	Replacement
Timer	SHIFT + TIMER SLEEP (Shift + Sleep / Timer)
Sleep	TIMER SLEEP (Sleep / Timer)
Clock	OPT-TOOLS SETUP (Setup / OPT /)
Edit/Remain	SIZE ZOOM (Zoom / Size)
PRGM	PROGRAM TV/RADIO (TV/Radio /)
Random	SHIFT + Prime Video RANDOM (Shift + Blue / Prime)
Repeat / Mono	SHIFT + APP REPEAT (Shift + Green / APP /)
Disc Direct Play 1	Left
Disc Direct Play 2	Up
Disc Direct Play 3	Right
Open/Close	SURROUND Eject (Eject / Surround)
1	TV 1 (1)
2	DVD 2 (2)
3	CD-STB 3 (3)
4	VIDEO 4 (4)
5	TAPE 5 (5)
6	TUNER 6 (6)

Original	Replacement
7	AUX-HDD 7 (7)
8	USB 8 (8)
9	BLUETOOTH 9 (9)
0	HDMI-SAT 0 (0)
+10	-/-- GUIDE EPG (Guide / EPG / -/--)
BBE	LANG I/II AUDIO (Audio / Lang I/II)
GEQ MANU	CH PAGE − (CH- / Page-)
Karaoke	GOTO TEXT (Text / Goto)
T-Bass	TITLE SOUND (Sound / Title)
GEQ PRGM	CH PAGE + (CH+ / Page+)
GEQ PRGM	EQ SUBTITLE (Subtitle / EQ)
DSP PRGM	LIST SMART (Smart / List)
CD	NETFLIX SEARCH (Red / Netflix / Search)
CD	SHIFT + CD-STB 3 (Shift + 3)
<> Direction	SLOW ▶ (Play / Slow)
Video/AUX	SHIFT + VIDEO 4 (Shift + 4)
Video/AUX	APP REPEAT (Green / APP / Repeat)

https://all-remote-controls.co.uk/en/Aiwa/1066927-25620-replacement-remote-control-for-Aiwa-RC-TN999.html

Original	Replacement	Original	Replacement
Video/AUX	SHIFT + AUX-HDD 7 (Shift + 7)		
I<<</Down/<<	TUNE- << / Tune-		
I<<</Down/<<	PRESET- I<< / Preset-		
>>/Up/>>I	PRESET+ >>I / Preset+		
>>/Up/>>I	TUNE+ >> / Tune+		
Tuner/Band	YouTube REPEAT A-B Yellow / YouTube / Repeat		
Tuner/Band	SHIFT + TUNER 6 (Shift + 6)		
Rec/Rec Mute	REC MODE Rec / Rec Mode		
Stop	HOLD Stop / Hold		
Pause	STEP-FREEZE Pause / Step / Freeze		
Tape/Deck 1/2	SHIFT + TAPE 5 (Shift + 5)		
Tape/Deck 1/2	Prime Video RANDOM Blue / Prime Video / Random		
Power	Power		
Volume Down	VOL - Vol-		
Volume Up	VOL + Vol+		