Original		Replacement		Original		Replacement	
	Power		Power		0		0
	Prog+		CH+ / Page+				
	Prog-		CH- / Page-				
	1		1				
	2		2				
	3		3				
	Tv/ VTR		TV/ Radio /				
	Vol +		Vol +				
	4		4				
	5		5				
	6		6				
	Data Screen		Display / Media				
	Vol -		Vol -				
	7		7				
	8		8				
	9		9				
	-/--		Guide / EPG / -/--				

Original	Replacement	Original	Replacement
Check	Smart / List	Input Select	AV / Input / RDS
Clear	Exit / Cancel / Clear	Vol -	Vol -
On/Off Timer/Rec	Sleep / Timer	7	7
Power	Power	8	8
Prog+	CH+ / Page+	9	9
Prog-	CH- / Page-	Timer On	Green / APP / Repeat
Transmit	Red / Netflix / Search	Counter Reset	Yellow / YouTube / Repeat
1	1	Index	Info / Angle
2	2	-/--	Guide / EPG / -/--
3	3	0	0
Rec Mode	SHIFT + REC MODE / Shift + Rec / Rec Mode	Up	Up
TV/VTR	TV/Radio /	PinP	Picture / Format
Vol +	Vol +	Shift	Text / Goto
4	4	Digital Off	Zoom / Size
5	5	Menu	Menu / Home
6	6	Left	Left
Data Screen	Display / Media	Execute	OK

Original		Replacement		Original		Replacement	
	Right		Right	FF	>>/ FF	TUNE+	>> / Tune+
EDIT MONITOR	Edit Monitor	EQ SUBTITLE	Subtitle / EQ	SEARCH	Search >>	PRESET+	>>I / Preset+
INDEX MARK	Index Mark	OPT-TOOLS SETUP	Setup / OPT /	STOP	Stop	HOLD	Stop / Hold
INDEX ERASE	Index Erase	PC FAV MARKER	Fav / Marker / PC				
	Down		Down				
	< Frame	SHIFT	+ Shift + Left				
FRAME	>I < Frame	SHIFT	+ OK Shift + OK				
	Frame >	SHIFT	+ Shift + Right				
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze				
REC	Rec	REC MODE	Rec / Rec Mode				
SLOW-	Slow-	SHIFT	+ CH PAGE Shift + CH- /				
SLOW+	Slow+	SHIFT	+ CH PAGE Shift + CH+ /				
AUDIO DUB	Audio Dub	LANG I/II AUDIO	Audio / Lang I/II				
PLAY	Play	SLOW	Play / Slow				
HIGH SPEED REWIND	<<< High Speed Remain	RETURN BACK	Back / Return				
SEARCH	<< Search	PRESET-	I<< / Preset-				
REW	<</ REW	TUNE-	<< / Tune-				

Original	Replacement	Original	Replacement
Check	Smart / List	Input Select	AV / Input / RDS
Clear	Exit / Cancel / Clear	Vol -	Vol -
On/Off Timer Rec	Sleep / Timer	7	7
Power	Power	8	8
Prog+	CH+ / Page+	9	9
Prog-	CH- / Page-	Timer On	Green / APP / Repeat
Transmit	Red / Netflix / Search	Counter Reset	Yellow / YouTube / Repeat
1	1	Index	Info / Angle
2	2	-/--	Guide / EPG / -/--
3	3	0	0
Rec Mode	Shift + Rec / Rec Mode	Up	Up
Tv/VTR	TV/Radio /	PinP	Picture / Format
Vol +	Vol +	Shift	Text / Goto
4	4	Digital Off	Zoom / Size
5	5	Menu	Menu / Home
6	6	Left	Left
Data Screen	Display / Media	Execute	OK

Original		Replacement		Original		Replacement	
	Right		Right	FF	>>/ FF	TUNE+	>> / Tune+
EDIT MONITOR	Edit Monitor	EQ SUBTITLE	Subtitle / EQ	SEARCH	Search >>	PRESET+	>>I / Preset+
INDEX MARK	Index Mark	OPT-TOOLS SETUP	Setup / OPT /	STOP	Stop	HOLD	Stop / Hold
INDEX ERASE	Index Erase	PC FAV MARKER	Fav / Marker / PC				
	Down		Down				
	< Frame	SHIFT	+ Shift + Left				
FRAME	>I < Frame	SHIFT	+ OK Shift + OK				
	Frame >	SHIFT	+ Shift + Right				
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze				
REC	Rec	REC MODE	Rec / Rec Mode				
SLOW-	Slow-	SHIFT	+ CH PAGE Shift + CH- /				
SLOW+	Slow+	SHIFT	+ CH PAGE Shift + CH+ /				
AUDIO DUB	Audio Hub	LANG I/II AUDIO	Audio / Lang I/II				
PLAY	Play	SLOW	Play / Slow				
HIGH SPEED REWIND	<<< High Speed Remain	RETURN BACK	Back / Return				
SEARCH	<< search	PRESET-	I<< / Preset-				
REW	<</ REW	TUNE-	<< / Tune-				

Original	Replacement	Original	Replacement
Check	Smart / List	Input Select	AV / Input / RDS
Clear	Exit / Cancel / Clear	Vol -	Vol -
On/Off Timer Rec	Sleep / Timer	7	7
Power	Power	8	8
Prog+	CH+ / Page+	9	9
Prog-	CH- / Page-	Timer On	Green / APP / Repeat
Transmit	Red / Netflix / Search	Counter Reset	Yellow / YouTube / Repeat
1	1	Index	Info / Angle
2	2	-/--	Guide / EPG / -/--
3	3	0	0
Rec Mode	Shift + Rec / Rec Mode	Up	Up
Tv/VTR	TV/Radio /	PinP	Picture / Format
Vol +	Vol +	Shift	Text / Goto
4	4	Digital Off	Zoom / Size
5	5	Menu	Menu / Home
6	6	Left	Left
Data Screen	Display / Media	Execute	OK

Original		Replacement		Original		Replacement	
	Right		Right	FF	>>/ FF	TUNE+	>> / Tune+
EDIT MONITOR	Edit Monitor	EQ SUBTITLE	Subtitle / EQ	SEARCH	Search >>	PRESET+	>>I / Preset+
INDEX MARK	Index Mark	OPT-TOOLS SETUP	Setup / OPT /	STOP	Stop	HOLD	Stop / Hold
INDEX ERASE	Index Erase	PC FAV MARKER	Fav / Marker / PC				
	Down		Down				
	< Frame	SHIFT	+ Shift + Left				
FRAME	>I < Frame	SHIFT	+ OK Shift + OK				
	Frame >	SHIFT	+ Shift + Right				
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze				
REC	Rec	REC MODE	Rec / Rec Mode				
SLOW-	Slow-	SHIFT	+ CH PAGE Shift + CH- /				
SLOW+	Slow+	SHIFT	+ CH PAGE Shift + CH+ /				
AUDIO DUB	Audio Dub	LANG I/II AUDIO	Audio / Lang I/II				
PLAY	Play	SLOW	Play / Slow				
HIGH SPEED REWIND	<<</ High Speed Rewind	RETURN BACK	Back / Return				
SEARCH	<< Search	PRESET-	I<< / Preset-				
REW	<</ REW	TUNE-	<< / Tune-				