Mandis shop

DIGITAL-PHOTO-FRAME

Original		Replacement	
POWER	Power		Power
UP	Up		Up
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
LEFT	Left		Left
ENTER	Enter	OK	OK
RIGHT	Right		Right
FUNCTION	Function	HOME MENU	Menu / Home
DOWN	Down		Down
OSD	OSD	MEDIA DISPLAY	Display / Media
I<		PRESET-	I<< / Preset-
PLAY/ PAUSE	Play	SLOW	Play / Slow
PLAY/ PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
>I		PRESET+	>>I / Preset+
<<		TUNE-	<< / Tune-
STOP/ EXIT	Stop	HOLD	Stop / Hold
STOP/ EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
>>		TUNE+	>> / Tune+

Original		Replacement	
VOL+	Vol+	VOL	Vol+
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
VOL–	Vol-	VOL	Vol-

https://all-remote-controls.co.uk/en/Aluratek/1067314-79719-replacement-remote-control-for-Aluratek-Digital-Photo-Frame.html