Original		Replacement	
STANDBY	Power		Power
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
INTRO PREVIEW	Preview/Intro	RETURN BACK	Back / Return
	Dolby	LANG I/II AUDIO	Audio / Lang I/II
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
TITLE/PBC ALT	ALT/Title/PBC	TITLE SOUND	Sound / Title
0/10	0/10	HDMI - SAT 0	0

Original		Replacement	
10+	10+	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
SETUP MENU	Menu/Setup	HOME MENU	Menu / Home
RETURN EXIT	Exit/Return	CLEAR EXIT CANCEL	Exit / Cancel / Clear
SUBTITLE SUB	Sub./Subtitle	EQ SUBTITLE	Subtitle / EQ
◆/CH+	Up	▲	Up
◆/CH-	CH+	+ CH PAGE	CH+ / Page+
▶	Right	▶	Right
◀	Left	◀	Left
▶/ENTER	Enter	OK	OK
▶/ENTER	Play	SLOW ▶	Play / Slow
◆/CH-	CH-	CH PAGE −	CH- / Page-
◆/CH-	Down	▼	Down
MENU TEXT	Blue/Text/Menu	Prime Video RANDOM	Blue / Prime Video / Random
AUDIO AUD	Green/Audio	APP REPEAT	Green / APP / Repeat
PAUSE II	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
PAUSE II	Pause	STEP - FREEZE II	Pause / Step / Freeze
LANGUAGE LANG	Red/Language	NETFLIX SEARCH	Red / Netflix / Search

Original		Replacement	
ANGLE LIST	List/Angle	LIST SMART	Smart / List
DISPLAY INFO.	Info/Display	ANGLE INFO	Info / Angle
FUNCTION DVD/DVB	DVD/DVB/Functio	MEDIA DISPLAY	Display / Media
VOLUME +	Vol+	+ VOL	Vol+
TV/RADIO	Tv/Radio	PROGRAM TV/ RADIO	TV/Radio /
GAME	Game	FORMAT PICTURE	Picture / Format
–	Vol-	VOL –	Vol-
FAVOR.	Favor.	PC FAV MARKER	Fav / Marker / PC
AUTO SCAN	Auto Scan	RDS AV INPUT	AV / Input / RDS
STOP	Stop	HOLD ■	Stop / Hold
SLOW	Slow	SHIFT + SLOW ▶	Shift + Play /
PROGRAM EPG.	EPG/Program	-/-- GUIDE EPG	Guide / EPG / -/--
⏮	I<<	PRESET- ⏮	I<< / Preset-
⏭	>>I	PRESET+ ⏭	>>I / Preset+
CLEAR	Clear	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
◀◀	<<	TUNE- ◀◀	<< / Tune-
▶▶	>>	TUNE+ ▶▶	>> / Tune+

Original		Replacement	
MEMORY	Memory	TOP MENU D.MENU	D.Menu / Top
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
A-B	A-B	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
A-TIME	A-Time	OPT-TOOLS SETUP	Setup / OPT /