Original		Replacement	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
	<<	TUNE-	<< / Tune-
	Zoom	SIZE ZOOM	Zoom / Size
	[I]	MEDIA DISPLAY	Display / Media
	[--]	LIST SMART	Smart / List
	>>	TUNE+	>> / Tune+
	I<<	PRESET-	I<< / Preset-
	Play/Pause 2	STEP-FREEZE	Pause / Step / Freeze
	Play/Pause 1	SLOW	Play / Slow
	>>I	PRESET+	>>I / Preset+
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
	M	HOME MENU	Menu / Home

Original		Replacement	
	S	RDS AV INPUT	AV / Input / RDS
	Back	RETURN BACK	Back / Return
	Vol-	VOL	Vol-
	Vol+	VOL	Vol+

https://all-remote-controls.co.uk/en/WiMiUS/1067574-96363-replacement-remote-control-for-WiMiUS-P20.html