Mandis shop

Philips 996580006517

Original		Replacement	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
	Play/Pause	SLOW	Play / Slow
	I<	PRESET-	I<< / Preset-
	>I	PRESET+	>>I / Preset+
MOVIE	Movie	FORMAT PICTURE	Picture / Format
NIGHT	Night	TIMER SLEEP	Sleep / Timer
HDMI ARC	HDMI ARC	OPT-TOOLS SETUP	Setup / OPT /
VOICE	Voice	TITLE SOUND	Sound / Title
MUSIC	Music	LANG I/II AUDIO	Audio / Lang I/II
BASS +	Bass+		Up
AUDIO SYNC -	Audio Sync -		Left
AUDIO SYNC +	Audio Sync +		Right
BASS -	Bass-		Down
	Vol+	VOL +	Vol+
TREBLE +	Treble+	CH PAGE +	CH+ / Page+
	Vol-	VOL -	Vol-

Original		Replacement	
TREBLE -	Treble-	CH PAGE -	CH- / Page-
COAX	Coax	TV 1	1
OPTICAL	Optical	DVD 2	2
AUDIO IN	Audio In	LIST SMART	Smart / List
AUX	Aux	AUX - HDD 7	7
USB	USB	USB 8	8
	Bluetooth	BLUETOOTH 9	9
DIM	DIM	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer

https://all-remote-controls.co.uk/en/Philips/1067735-66030-replacement-remote-control-for-Philips-996580006517.html