Mandis shop

Sony RMT-708

Original	Replacement
Play	Play / Slow
Start/Stop	Power
Start/Stop	Rec / Rec Mode
<<	<< / Tune-
>>	>> / Tune+
Stop	Stop / Hold
T	CH+ / Page+
Pause	Pause / Step / Freeze
I>/Slow	Right
I>/Slow	Shift + Play /
W	CH- / Page-
Display	Display / Media

Original	Replacement

https://all-remote-controls.co.uk/en/Sony/1068047-6337-replacement-remote-control-for-Sony-RMT-708-146757423.html