Mandis shop

# Sony RMT-708

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| PLAY | Play | SLOW | Play / Slow | | |
| START/STOP | Start/Stop | | Power | | |
| START/STOP | Start/Stop | REC MODE | Rec / Rec Mode | | |
| REW | << | TUNE- | << / Tune- | | |
| FF | >> | TUNE+ | >> / Tune+ | | |
| STOP | Stop | HOLD | Stop / Hold | | |
| | T | CH PAGE + | CH+ / Page+ | | |
| PAUSE | Pause | STEP-FREEZE | Pause / Step / Freeze | | |
| SLOW | I>/Slow | | Right | | |
| SLOW | I>/Slow | SHIFT + SLOW | Shift + Play / | | |
| | W | CH PAGE - | CH- / Page- | | |
| DISPLAY | Display | MEDIA DISPLAY | Display / Media | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

https://all-remote-controls.co.uk/en/Sony/1068047-6337-replacement-remote-control-for-Sony-RMT-708-146757423.html