Original		Replacement	
POWER	Power		Power
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
OSD	OSD	MEDIA DISPLAY	Display / Media
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
STEP	Step	SHIFT + STEP - FREEZE	Shift + Pause / Step /
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
DVD/USB	DVD/USB	RDS AV INPUT	AV / Input / RDS
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
0/10	0/10	HDMI - SAT 0	0
10+	10+	-/-- GUIDE EPG	Guide / EPG / -/--

Original		Replacement	
TIME	Time	TIMER SLEEP	Sleep / Timer
TITLE	Title	TITLE SOUND	Sound / Title
	Up		Up
MENU	Menu	HOME MENU	Menu / Home
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
	I<<	PRESET-	I<< / Preset-
L/R	L/R	NETFLIX SEARCH	Red / Netflix / Search
N/P	N/P	Prime Video RANDOM	Blue / Prime Video / Random
	<<	TUNE-	<< / Tune-
VOL-	Vol-	VOL -	Vol-
VOL+	Vol+	+ VOL	Vol+
	>>I	PRESET+	>>I / Preset+

Original		Replacement	
	Play	SLOW	Play / Slow
	Pause	STEP - FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
	>>	TUNE+	>> / Tune+
VIDEO	Video	SHIFT + VIDEO 4	Shift + 4
PROG	Prog	PROGRAM TV/RADIO	TV/Radio /
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
A-B	A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
PBC	PBC	GOTO TEXT	Text / Goto
RETURN	Return	RETURN BACK	Back / Return
SLOW	Slow	SHIFT + SLOW	Shift + Play /
LANGUAGE	Language	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
ANGLE	Angle	ANGLE INFO	Info / Angle
RESET	Reset	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear

Original	Replacement