Original		Replacement	
POWER	Power		Power
CBL/SAT	CBL/SAT	HDMI - SAT 0	0
MEDIA PLAYER	Media Player	-/-- GUIDE EPG	Guide / EPG / -/--
Blu-ray/ DVD	Blu-ray/DVD	DVD 2	2
GAME	Game	PC FAV MARKER	Fav / Marker / PC
AUX	AUX	AUX - HDD 7	7
TUNER	Tuner	TUNER 6	6
PHONO	Phono	TAPE 5	5
TV AUDIO	TV Audio	TV 1	1
CD	CD	CD - STB 3	3
USB	USB	USB 8	8
Bluetooth	Bluetooth	BLUETOOTH 9	9
INTERNET RADIO	Internet Radio	VIDEO 4	4
	Heos	LIST SMART	Smart / List
CH / PAGE	CH+	+ CH PAGE	CH+ / Page+
ECO	ECO	SIZE ZOOM	Zoom / Size
VOLUME	Volume+	+ VOL	Vol+

Original		Replacement	
CH / PAGE	CH-	CH PAGE –	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
VOLUME	Volume-	VOL –	Vol-
INFO	Info	ANGLE INFO	Info / Angle
OPTION	Option	HOME MENU	Menu / Home
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
TUNE-	I<</Tune-	PRESET-	I<< / Preset-
TUNE-	I<</Tune-	TUNE-	<< / Tune-
	Play/Pause	SLOW	Play / Slow
TUNE+	>>I/Tune+	PRESET+	>>I / Preset+
TUNE+	>>I/Tune+	TUNE+	>> / Tune+

Original		Replacement	
BAND	Band	MEDIA DISPLAY	Display / Media
MODE	Stop/Mode	HOLD	Stop / Hold
MEMORY	Memory	SURROUND	Eject / Surround
1	Smart Select 1	NETFLIX SEARCH	Red / Netflix / Search
SMART 2	Smart Select 2	APP REPEAT	Green / APP / Repeat
SELECT 3	Smart Select 3	YouTube REPEAT A-B	Yellow / YouTube / Repeat
4	Smart Select 4	Prime Video RANDOM	Blue / Prime Video / Random
SPEAKER	Speaker	EQ SUBTITLE	Subtitle / EQ
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
SOUND MODE	Sound Mode	TITLE SOUND	Sound / Title

Original	Replacement

Original		Replacement	
POWER	Power		Power
CBL/SAT	CBL/SAT	HDMI - SAT 0	0
MEDIA PLAYER	Media Player	-/-- GUIDE EPG	Guide / EPG / -/--
Blu-ray/ DVD	Blu-ray/DVD	DVD 2	2
GAME	Game	PC FAV MARKER	Fav / Marker / PC
AUX	AUX	AUX - HDD 7	7
TUNER	Tuner	TUNER 6	6
PHONO	Phono	TAPE 5	5
TV AUDIO	TV Audio	TV 1	1
CD	CD	CD - STB 3	3
USB	USB	USB 8	8
Bluetooth	Bluetooth	BLUETOOTH 9	9
INTERNET RADIO	Internet Radio	VIDEO 4	4
	Heos	LIST SMART	Smart / List
CH / PAGE	CH+	+ CH PAGE	CH+ / Page+
VOLUME	Volume+	+ VOL	Vol+
CH / PAGE	CH-	CH PAGE –	CH- / Page-

Original		Replacement	
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
VOLUME	Volume-	VOL –	Vol-
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
TUNE-	I<<</Tune-	PRESET-	I<< / Preset-
TUNE-	I<<</Tune-	TUNE-	<< / Tune-
►/II	Play/Pause	SLOW	Play / Slow
TUNE+	>>I/Tune+	PRESET+	>>I / Preset+
TUNE+	>>I/Tune+	TUNE+	>> / Tune+
BAND	Band	MEDIA DISPLAY	Display / Media
MODE	Stop/Mode	HOLD	Stop / Hold
MEMORY	Memory	SURROUND	Eject / Surround
1	Smart Select 1	NETFLIX SEARCH	Red / Netflix / Search

Original	Replacement	Original	Replacement
SMART 2 Smart Select 2	APP REPEAT Green / APP / Repeat		
SELECT 3 Smart Select 3	YouTube REPEAT A-B Yellow / YouTube / Repeat		
4 Smart Select 4	Prime Video RANDOM Blue / Prime Video / Random		
SLEEP Sleep	TIMER SLEEP Sleep / Timer		