Original		Replacement	
Power	Power	Power	Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
ZAPP FAV	FAV/ ZAPP	FAV PRE-CH	Pre Ch
TXT	TXT	REPEAT TEXT	Text
Red	Red	A	Red
Green	Green	B	Green
Yellow	Yellow	C	Yellow
Blue	Blue	D	Blue

Original		Replacement	
TV-G EXIT	Exit/TV-G	CLEAR EXIT	Exit
?	?	HOME SMART	Smart
@	@	APP MEDIA	Media
MENU	Menu/i	TOP MENU MENU	Menu
BACK	Back	RETURN BACK	Back
TOOLS	Tools	SETTINGS OPT	Options
GUIDE	Guide	-/-- GUIDE	Guide
OK	OK	OK	Ok
Up	Up		Up
Down	Down		Down
Right	Right		Right
Left	Left		Left
+	Vol +	+ VOL	Vol +
-	Vol -	VOL -	Vol -
+ P	PR+	+ CH	Ch +
P -	PR-	CH -	Ch -
AV	AV	TIMER AV	AV

Original		Replacement		Original	Replacement
	Mute	MUTE	Mute		
	I <		I <<		
	>I		>>I		
	<<		<<		
	>>		>>		
	Rec	REC MODE	Rec		
	Play	PLAY MODE	Play		
	Pause		Pause		
	Stop		Stop		
3D	3D/Search	PICTURE FORMAT	Format		
	. . O/Audio	SOUND DUAL	Dual		
	[. . .] . .	AD SUBT	Subt		
PIP/ECO	PIP/ECO	ECO 3D	3D		
CEC My Media	My Media/CEC	SEARCH TV/R	TV/R		