| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | PIP | | Info / Angle |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | [ <>] | | Picture / Format |
| | >I | | >>I / Preset+ |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | ? | | Smart / List |
| | I< | | I<< / Preset- |
| | 0 | | 0 |
| | Mute | | Mute / Dimmer |

| Original | | Replacement | |
|---|---|---|---|
| | i / OSD | | Display / Media |
| | Z/ Disc Menu | | Menu / Home |
| | Up | | Up |
| | P+ | | CH+ / Page+ |
| | Left | | Left |
| | Vol - | | Vol - |
| | OK | | OK |
| | Right | | Right |
| | Vol + | | Vol + |
| | TXT | | Text / Goto |
| | << | | << / Tune- |
| | Down | | Down |
| | P- | | CH- / Page- |
| | TV-G | | Guide / EPG / -/-- |
| | >> | | >> / Tune+ |
| | Red/ Image/ I > | | Red / Netflix / Search |
| | Green/ Timer | | Green / APP / Repeat |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Play | SLOW Play / Slow | | |
| Yellow/ Pause | YouTube REPEAT A-B Yellow / YouTube / Repeat | | |
| Pause | STEP-FREEZE Pause / Step / Freeze | | |
| Blue/ Sound | Prime Video RANDOM Blue / Prime Video / Random | | |
| Stop | HOLD Stop / Hold | | |
| Blue/ Sound | TITLE SOUND Sound / Title | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | Audio | | Audio / Lang I/II |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | [ <>] | | Zoom / Size |
| | >I | | >>I / Preset+ |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | ? | | Smart / List |
| | I< | | I<< / Preset- |
| | 0 | | 0 |
| | i / OSD | | Display / Media |

| Original | | Replacement | |
|---|---|---|---|
| | Disc Menu | | D. Menu / Top |
| | Disc Menu | | Menu / Home |
| | Up | | Up |
| | P+ | | CH+ / Page+ |
| | Left | | Left |
| | Vol - | | Vol - |
| | OK | | OK |
| | Right | | Right |
| | Vol + | | Vol + |
| | TXT | | Text / Goto |
| | << | | << / Tune- |
| | Down | | Down |
| | P- | | CH- / Page- |
| | TV-G | | Guide / EPG / -/-- |
| | >> | | >> / Tune+ |
| | Red/Picture | | Picture / Format |
| | Red/Picture | | Red / Netflix / Search |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Green / Timer | TIMER SLEEP — Sleep / Timer | | |
| Play | SLOW — Play / Slow | | |
| Green / Timer | APP REPEAT — Green / APP / Repeat | | |
| Yellow/Pause | YouTube REPEAT A-B — Yellow / YouTube / Repeat | | |
| Pause | STEP-FREEZE — Pause / Step / Freeze | | |
| Blue/Sound | TITLE SOUND — Sound / Title | | |
| Stop | HOLD — Stop / Hold | | |
| Blue/Sound | Prime Video RANDOM — Blue / Prime Video / Random | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | Audio | | Audio / Lang I/II |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | [ <>] | | Zoom / Size |
| | >I | | >>I / Preset+ |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | ? | | Smart / List |
| | I< | | I<< / Preset- |
| | 0 | | 0 |
| | Mute | | Mute / Dimmer |

| Original | | Replacement | |
|---|---|---|---|
| | i / OSD | | Display / Media |
| | Z/ Disc Menu | | Menu / Home |
| | Up | | Up |
| | P+ | | CH+ / Page+ |
| | Left | | Left |
| | Vol - | | Vol - |
| | OK | | OK |
| | Right | | Right |
| | Vol + | | Vol + |
| | TXT | | Text / Goto |
| | << | | << / Tune- |
| | Down | | Down |
| | P- | | CH- / Page- |
| | TV-G | | Guide / EPG / -/-- |
| | >> | | >> / Tune+ |
| | Red/ Image/ I> | | Red / Netflix / Search |
| | Red/ Image/ I> | | Shift + Play / Slow |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Green/Timer | APP REPEAT Green / APP / Repeat | | |
| Play | SLOW Play / Slow | | |
| Green/Timer | TIMER SLEEP Sleep / Timer | | |
| Pause | STEP-FREEZE Pause / Step / Freeze | | |
| Yellow/Pause | YouTube REPEAT A-B Yellow / YouTube / Repeat | | |
| Blue/Sound | Prime Video RANDOM Blue / Prime Video / Random | | |
| Stop | HOLD Stop / Hold | | |
| Blue/Sound | TITLE SOUND Sound / Title | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | PIP/Audio | | Audio / Lang I/II |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | [<>] | | Zoom / Size |
| | >I | | >>I / Preset+ |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | ? | | Smart / List |
| | I< | | I<< / Preset- |
| | 0 | | 0 |
| | i/OSD | | Display / Media |

| Original | | Replacement | |
|---|---|---|---|
| | Z/Disc Menu | | Menu / Home |
| | P+ | | CH+ / Page+ |
| | Up | | Up |
| | Left | | Left |
| | Vol - | | Vol - |
| | OK | | OK |
| | Right | | Right |
| | Vol + | | Vol + |
| | TXT | | Text / Goto |
| | << | | << / Tune- |
| | P- | | CH- / Page- |
| | Down | | Down |
| | TV-G | | Guide / EPG / -/-- |
| | >> | | >> / Tune+ |
| | Red/Image/I> | | Picture / Format |
| | Red/Image/I> | | Red / Netflix / Search |
| | Green/Timer | | Green / APP / Repeat |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Play | SLOW Play / Slow | | |
| Green/Timer | TIMER SLEEP Sleep / Timer | | |
| Yellow/Pause | YouTube REPEAT A-B Yellow / YouTube / Repeat | | |
| Pause | STEP-FREEZE Pause / Step / Freeze | | |
| Blue/Sound | Prime Video RANDOM Blue / Prime Video / Random | | |
| Stop | HOLD Stop / Hold | | |
| Blue/Sound | TITLE SOUND Sound / Title | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |