Original		Replacement	
POWER	Power	POWER	Power
MUTE	Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
CH.LIST	CH. List	GUIDE	Guide
RECALL	Recall	RETURN BACK	Back
VOL +	Vol+	VOL +	Vol +
VOL −	Vol-	VOL −	Vol -
PIC.MODE	Pic. Mode	SHIFT + PICTURE FORMAT	Shift + Format

Original		Replacement	
S.MODE	S.Mode	SHIFT + SOUND DUAL	Shift + Dual
SOURCE	Source	TIMER AV	AV
CH +	CH+	CH +	Ch +
CH −	CH-	CH −	Ch -
▲	Up	▲	Up
◀	Left	◀	Left
OK	OK	OK	Ok
▶	Right	▶	Right
▼	Down	▼	Down
EXIT	Exit	CLEAR EXIT	Exit
MENU	Menu	TOP MENU MENU	Menu
HOME	Home	HOME SMART	Smart
MOUSE	Mouse	E-MANUAL D.MENU	D. Menu
IE	IE	APP MEDIA	Media
●	Red	A	Red
●	Green	B	Green
●	Yellow	C	Yellow

Original		Replacement		Original	Replacement
	Blue	D	Blue		
TV/RADIO	TV / Radio	SEARCH TV/R	TV/R		
ASPECT	Aspect	PICTURE FORMAT	Format		
SLEEP	Sleep	PROG SLEEP	Sleep		
SUBTITLE	Subtitle	AD SUBT	Subt		
INDEX	Index	DISC NAV LIST	List		
REVEAL	Reveal	SHIFT + OK	Shift + Ok		
TEXT	Text	REPEAT TEXT	Text		
SIZE	Play / Size	PLAY MODE ▶	Play		
AUDIO	Audio	SOUND DUAL	Dual		
DISPLAY	Display	DISPLAY INFO	Info		
SUBPAGE	Pause /	❚❚	Pause		
HOLD	Stop / Hold	■	Stop		
⏮	I<<	⏮	I<<		
⏭	>>I	⏭	>>I		
◀◀	<<	◀◀	<<		
▶▶	>>	▶▶	>>		