Mandis shop

FIREPLACE1

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power | Power | | |
| Timer | Freeze / Timer | | |
| III | Comp / Video | | |
| Fire- | - / Stop | | |
| Fire+ | + / Play | | |

https://all-remote-controls.co.uk/en/Alpaca/1065490-79326-replacement-remote-control-for-Alpaca-Fire-Fireplace1.html