Mandis shop

193334-B10

Original		Replacement	
On Off	On / Off		Power
Sleep	Sleep	PROG SLEEP	Sleep
Volume	Volume +	VOL +	Vol +
Volume	Volume -	VOL −	Vol -
CD	CD Play/Pause	PLAY MODE ▶	Play
CD	CD Play/Pause	⏸	Pause
CD ■	CD Stop	■	Stop
FM	FM	CH +	Ch +
AM	AM	CH −	Ch -
AUX	AUX	APP MEDIA	Media
Track Tune	Track - / Tune -	◀	Left
Track Tune	Track - / Tune -	⏮	I<<
Track Tune	Track - / Tune -	≪	<<
Track Tune	Track + / Tune +	▶	Right
Track Tune	Track + / Tune +	≫	>>
Track Tune	Track + / Tune +	⏭	>>I
Mute	Mute	MUTE	Mute

Original		Replacement	
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6

https://all-remote-controls.co.uk/en/BOSE/1058485-91402-replacement-remote-control-for-BOSE-WAVE-RADIO-CD-White-193334-B10.html