Mandis shop

T4

Original		Replacement	
	Power		Power
AUX	AUX	A	Red
DIGITAL	Digital	D	Blue
	Bluetooth	B	Green
	Play	PLAY MODE	Play
	Pause		Pause
	>>I		>>I
	I<<		I<<
	Vol+	VOL +	Vol +
	Vol-	VOL −	Vol -

Original	Replacement

https://all-remote-controls.co.uk/en/CREATIVE/1062147-89784-replacement-remote-control-for-CREATIVE-T4.html